


# A-SPIRE

## PRODUCT MANUAL



### POWER ON/OFF

To power the headset on or off, press and hold ① for 2 seconds.

### BATTERY STATUS

While the headset is turned on, shortly press ① to get the headset battery level.

### CONNECTION

#### USB ② - MAIN GAMING USE, and CHARGING




For the best gaming performance and charging, connect using the USB Type-C cable.

#### AUX ③ - CONSOLE USE

For consoles where a USB connection is not possible, connect using the AUX cable.

#### BLUETOOTH - CASUAL USE

While the headset is off, press and hold ① for 5 seconds to enter pairing mode.



### NOISE CANCELLING

Shortly press ④ to switch between noise cancelling modes.

### EQUALIZER CONTROL

While audio is playing, press and hold ④ to switch between equalizer modes:

- One beep signals music mode.
- Two beeps signal gaming mode.

### VOICE ASSISTANT

Double press ④ to activate your smartphone's given voice assistant.

### MUSIC CONTROL

#### PLAY/PAUSE MUSIC ▶||


Single press ⑤.

#### ADJUST VOLUME ◀|▶

Shortly press ⑥ for volume up, and shortly press ⑦ for volume down.

#### PREVIOUS/NEXT TRACK ◀|▶

Long press ⑥ for next track, and long press ⑦ for previous track.





### PHONE CONTROL

#### ANSWER/HANG UP ☎/↶

Shortly press ⑤ to answer an incoming call, or to hang up during an ongoing call.

#### DECLINE INCOMING CALL ✕

Long press ⑤.



### LED INDICATION

#### ⑧ CONNECTION

- • • • • Bluetooth pairing mode

- — • Connected

- • • • • Not connected

- • • • • Incoming call

#### ⑨ CHARGE


- Charging

- Fully Charged

### BOOM ARM

Rotate the boom arm to a vertical or horizontal position to respectively mute or unmute the boom arm microphone.


Ensure that the green microphone symbol on the boomarm microphone faces your mouth, and that the foam tip is securely in place.



### HEADBAND ADJUSTMENT

Lengthen the headband by pulling the ear cups away from the top of the headband, until the desired length is reached. Each adjustment step is signified by a clicking sound.

To shorten the headband, push the ear cups back up into the top of the headband.



### REGULATORY



AceZone ApS hereby declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and all other applicable EU directive requirements. The complete declaration of conformity can be found at: [www.acezone.io/compliance](http://www.acezone.io/compliance)



This product conforms to all applicable Electromagnetic Compatibility Regulations 2016 and all other applicable UK regulations. The complete declaration of conformity can be found at: [www.acezone.io/compliance](http://www.acezone.io/compliance)

AceZone ApS hereby declares that this product is in compliance with the essential requirements per Radio Equipment Regulations 2017 and all other applicable UK regulations. The complete declaration of conformity can be found at: [www.acezone.io/compliance](http://www.acezone.io/compliance)

#### Important Safety Instructions

- Do not use this apparatus near water.
- Clean only with a dry cloth.

Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

### WARNINGS/CAUTIONS

- Do NOT use the headset at a high volume for any extended period.
  - To avoid hearing damage, use your headset at a comfortable, moderate volume level.
  - Turn the volume down on your device before placing the headset in/on your ears, then turn the volume up gradually until you reach a comfortable listening level.
- Do NOT use your headset while driving for phone calls or any other purpose.
- Do NOT use the headset with noise canceling mode at any time the inability to hear surrounding sounds may present a danger to yourself or others, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad, etc., and follow applicable laws regarding headset use.
  - Turn the headset off, or use the headset with noise canceling off and adjust your volume, to ensure you can hear surrounding sounds, including alarms and warning signals.
  - Be aware of how sounds that you rely on as reminders or warnings may vary in character when using the headset, even with transparency mode.
- Do NOT use the headset if they emit any loud unusual noise. If this happens, turn the headphones off and contact AceZone customer service.
- Remove the headset immediately if you experience a warning sensation or loss of audio.
- Do NOT use the headset as aviation communication headsets. Contains small parts which may be a choking hazard. Not suitable for children under age 3. This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.

### WARNINGS/CAUTIONS CONT.

- Do NOT use mobile phone adapters to connect headset to airplane seat jacks, as this could result in injury or property damage due to overheating.
- To reduce the risk of fire or electrical shock, do NOT expose this product to rain, liquids or moisture.
- Do NOT expose this product to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the product.
- Keep the product away from fire and heat sources. Do NOT place naked flame sources, such as lighted candles, on or near the product.
- Use this product only with an agency approved LPS power supply which meets local regulatory requirements (e.g., UL, CSA, VDE, CCC).
- Do NOT make unauthorized alterations to this product.
- If the battery leaks, do not allow the liquid to come in contact with the skin or eyes. If contact is made, seek medical advice.
- Do not expose products containing batteries to excessive heat (e.g. from storage in direct sunlight, fire or the like).
- Do NOT wear while charging



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.



## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with minimum distance 0mm between the radiator & your body.

## ISED Statement

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada.

L'exploitation est soumise aux deux conditions suivantes :

- (1) Cet appareil ne doit pas provoquer d'interférences.
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

l'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

### RF Exposure Statement

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with minimum distance 0mm between the radiator & your body.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. Cet équipement doit être installé et utilisé avec une distance minimale de 0 mm entre le radiateur et votre corps.