



Connection Tutorial



1. Open the settings in your devices.  
2. Open the bluetooth.  
3. Click the "LINKLIKE LY2" to connect.  
4. Enable the call and media.

Check the Battery Level



According to the system,you can check the battery level on the phone's negative one screen or the top bar.

Two Device Connection Explanation



1.Turn on the headphones.Enable the Bluetooth function on devices A and B. Connect on the device interface.(Quick connection is possible within 20 seconds)  
2.Connect to device A.click the multifunction button 5 times to waiting for connection again and connect to device B.  
If two devices are already connected,you will need to disconnect one of them first.  
(Note:If you cannot reconnect immediately,close and open the bluetooth function again.)

Connect device A

Connect device B

Click 5 times


Volume Synchronization (Important)



According to different systems,the sync function locations is different.You can find the sync function through the following steps:  
1. IOS system:Automatic sync, no need to set up.  
2. Android New system:Settings - Bluetooth - Headphone settings - Turn on volume sync function.  
3. Android Old system:Settings - About phone - Tap on the version number repeatedly (at least 8 times) to enter developer mode - Go back to the settings interface,system and updates - Developer options - Turn on Bluetooth absolute volume - Done (you can exit developer mode in the status bar).


Tip:To better control the volume and enjoy music,it is best to turn on the phone of sync function before use the headphones.



Function Button




- Click once: Play/Pause/Answer call  
Press for 2s: Hang up/Reject Call
- Click once: Volume +  
Press for 2s: Next song
- Click once: Volume -  
Press for 2s: Previous song

Multifunction Touch Button



- Wireless Connection
  - Click Once:Mode switch(ANC,Normal,Adaptive,Transparency Mode)
  - Click Twice:Enter/Exit game mode
  - Click Three Times:Enter/Exit voice assistant
- Independent Use State (using noise cancellation without device)
  - Click Once:Mode switch(ANC,Normal, Adaptive,Transparency Mode)
  - Click Twice:Enter/Exit independent use state
- Press for 3s:Power on/off
- Press  &  key for 5s:Factory reset
- Click Five Times:Enter/Exit waiting for connection

Magnetic Hibernation



Magnetic suction sleep,ready to activate at any time.  
(Automatic shutdown after 8 hours from sleep.)

Lighting Description

Function Description	Indicator Light Status
Battery level display	White light:80% to 100% Green light:50% to 80% Orange light:20% to 50% Red light:0% to 20%
Fully Charged	White light stays on for 10s
Power off	Red light stays on for 2s
Waiting for connection	White light breathes within 3 min
Connection Successful	White light stays on for 2s
Factory Reset Successful	White and red lights alternate flashing 2s
Low Battery Warning	Red light flashes quickly for 2s
NTC Over-High or Over-Low Temperature Protection Mode	Red light flashes quickly for 10s

Linklike

QUICK GUIDE

LKPC01012A

物料编码：LKPC01012A			平面部分	表面工艺: ①正反面印刷②双面过防刮花哑膜③啤		
物料名称：LinkLike LY2降噪环颈耳机快速指南卡						
结构部分	材 质：	157g双铜		单 位：	mm	
	成型尺寸:	80*160mm		展开尺寸:	160*160mm	
	结构设计:			压 线:	—————	
	结构修改:	XXXXX		针 刀 线:	- - - - -	
	日 期:			刀线相交:	- - - - -	
	备 注:	特别注意事项		坑 纹:		
特别说明：所有物料需要符合蓝禾《有害物质限用管理程序》LH-WI-0004（环保要求）				印刷颜色: <div><div>PANTONE 877C</div><div>C</div><div>M</div><div>Y</div><div>K</div></div>		
			平面设计: 方刚来			
			平面修改: XXXXX			
			日 期:24.01.03			
			备 注:			
			LOFFAN DESIGN 诸 凡 设 计			

