

# Hey there,

Congratulations on getting your very own FPods FT7 Truly Wireless Earpods with 3C NitroFast Charge, latest BT Version V5.3, 13mm extra deep bass drivers, Quad Mic ENC, 50ms low latency gaming mode, InstaSync Pairing and IPX4 rating. You can now truly sink into your world of sound. Your musical vibe begins here.

Quick Start Guide

TRULY WIRELESS STEREO EARPODS WITH 3C NITROFAST CHARGE AND QUAD MIC ENVIRONMENTAL NOISE CANCELLATION

**fastrack**  
**FPods**  
FT7

Included Components

2x Truly Wireless Earpods

1x Portable Charging Case

1x Type C Charging Cable

Quick Start Guide

Eargels (S,M,L)

Overview

Touch Area

Charging Pins

LED Indicator

LED Indicator

USB-C Charging Port

Getting Started

- Place the earpods in the charging case and close the lid.
- Make sure to charge the earpods before starting the pairing process.
- Open the charging case lid. Your earpods will automatically go into pairing mode.
- Turn ON your phone's Bluetooth settings, and search for "FPods FT7" and tap to pair and connect.
- Your earpods are now paired and ready for you to experience.
- With InstaSync the earpods will automatically re-connect to a previously paired device next time you open the charging case lid (Make sure the device's Bluetooth is ON).
- To charge the earpods, place them back into the case and close the lid.
- This will also power off the earpods.
- Use the right sized Eartips (S,M,L) for a better fit and experience.

Setup your FPods FX100

### Setup

- Power on: To turn on the earpods take them out of the case.
- Power off: Put the earpods in the case and close the lid to power off.
- To manually Power on the earpods, press and hold the buds for 3 seconds.
- To manually Power off the earpods, press and hold the buds for 5 seconds.
- To charge the earpods, place them in the charging case and close the lid.
- Please ensure to charge your earpods fully before using them.
- To charge the Charging Case, use the Type C charging cable provided in the box.
- Use a standard 5V / 1A adaptor for charging.

Reset

1. Take out the earpods from the Charging Case.

2. Unpair the earpods from the previously connected device.

3. Tap 5 times on L/R bud.

4. Red LED on both L and R buds blinks 3 times.

5. Your earpods are now reset and ready to pair again.

Controls

### Call Controls

- Call Answer: Double tap on L/R bud.
- Call Hangup: Double tap on L/R bud during the call.
- Call Reject/Decline: Press & hold on L/R bud for 2 seconds.

### Music Controls

- Play/Pause: Double tap on L/R bud.
- Increase Volume: Single tap on R bud.
- Decrease Volume: Single tap on L bud.
- Previous Track: Press & hold L bud for 2 seconds.
- Next Track: Press & hold R bud for 2 seconds.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

www.fastrack.in @fastrack @fastrackworld

Monopod Mode

You can take out any bud out of the Charging Case and start using it as Monopod.

- Call Answer - Double tap on bud.
- Call Reject - Press & hold the bud for 2 seconds.
- Call Hangup - Double tap on bud.
- Music Play/ Pause - Double tap on bud.
- Music volume decrease - Single tap on bud.
- Music previous track - Press & hold the bud for 2 seconds.

- Call Answer - Double tap on bud.
- Call Reject - Press & hold the bud for 2 seconds.
- Call Hangup - Double tap on bud.
- Music Play/ Pause - Double tap on bud.
- Music volume increase - Single tap on bud.
- Music next track - Press & hold the bud for 2 seconds.

Features

### Voice Assistant, Gaming Mode

- Tap 3 times on L/R bud to activate Voice Assistant.
- Tap 4 times on L/R bud to activate Gaming Mode.

Gaming Mode

Level up your gaming experience with the built-in low latency gaming mode.

Voice Assistant

Your voice assistant is just a few taps away.

Note - Remember to switch off gaming mode while listening to music for the best audio experience.

Features

Environmental Noise Cancellation (Quad Mic)

3C NitroFast Charge – 10 min charge gives 150 min playtime\*

40 Hours Playtime\*

Gaming Mode (Low Latency of 50 ms)

Sleek Design

InstaSync

13mm Driver

Latest BT version 5.3

\*As tested under optimal conditions at Titan Smart Labs.

LED Indications

### Earpods

- Power ON: Blue LED on for 1 second.
- Power OFF: Red LED on for 1 second.
- Pairing Mode: Blue & Red LED blinks on one bud and Blue LED blinks on the other bud once in every 5 seconds.
- Connected: LED off on both buds.

### Charging Case

- While charging: 4 white LED blinks as per the charging percentage.
- Full charge: 4 white LED's on.

Product Specifications

### Product Specifications:

- BT Version: V5.3
- Driver Size: 13mm
- Frequency Response: 20Hz – 20KHz
- Water Resistance: IPX4
- Total Playtime with Charging Case: 40 Hours
- Buds Charging Time: 30 min
- Case Charging Time: 90 min
- Charging Voltage: DC 5V
- Transmission Distance: 10m
- Earpods Battery Capacity: 35mAh
- Charging Case Battery Capacity: 350mAh

Care & Warranty

### The Don't's

- Do not expose the earpods to extreme temperature/ weather conditions.
- Don't use chemicals or detergent to clean your buds.
- Do not keep the case on charging for a longer time once it is fully charged.

### Terms of Warranty

The product comes with a One year limited warranty against manufacturing defects. T&C apply. Any damage to the earpods that is not a malfunctioning issue will void the product's warranty. Please take care of your buds to ensure prolonged service life. If you have any queries or need to raise a complaint, please call us on 1800-266-0123 or visit the nearest Fastrack store.

Note - For more details on the product, please visit [www.fastrack.in](http://www.fastrack.in)

Quickstart Guide

**fastrack**  
**FPods**  
FT7