

TOZO®

www.tozostore.com

FCC ID: 2ASWH-T10

EN

T10

Bluetooth Earbuds

tozostore

35

info@tozostore.com

www.tozostore.com

Thank you for purchasing the TOZO authentic product.

For more latest products, parts and accessories,

please visit: www.tozostore.com

For any assistance please contact Email: info@tozostore.com

Customization

To improve wearing experience, please select a best fit ear caps for you.

How to pair earbuds with your phone

For the first time, please take out the earbuds and then put it in the charging compartment for 2-3 seconds. The left and right earbuds will automatically power on and interconnect. (Wait for 6-7 seconds) The right earbud's indicator will turn red and blue alternately. And then, turn on the phone to search the BT device name "TOZO-T10-R" and click to connect.

Reset

(For any pairing issue / static issue, please reset it) With the earbuds turned off, press and hold both earbuds button for 10 seconds, until indicators flashes Purple 3 times. Then turn on the earbuds, and select TOZO-T10-R

If the phone claims "Connection Unsuccessful", Please delete all (TOZO-T10-R) records on your phone, then click to re-search and select TOZO-T10-R

Do Not select (TOZO-T10-L) The slave earbud (L) flash blue slowly means it have paired the master earbud (R) Automatically.

1: Put earbuds into your ear. (Make sure indicator-light side is on the bottom)

2: Rotating back earbuds to auricle side to fit snugly.

For best performance, please try all size of ear caps to find the best one for your ears.

Button Control

R

L

Click: Receive phone call

Click: Hang up phone call

Double click: Recall last number

Click: play/pause

Long press 2S: Reject phone call

Click: Receive phone call

Click: Hang up phone call

Double click: Recall last number

Click: play/pause

Long press 2S: Reject phone call

Function

Operation

LED indicators

Power OFF

When on, press and hold the earbud button for 3 seconds

Red flash 3 times

Power ON

When off, press and hold the earbud button for 5 seconds

Blue flash 3 times

NOTE: The Tight Sealed Button Design for Waterproof & Sweatproof

Specification

Support type: A2DP/HFP/HSP/AVRCP/SP

Charging box input: 5V/0.8A

Transmit power: Class2

Frequency Range: 2.402-2.480GHz

Transmission distance: 10M

Earbuds battery: 50mAh/3.7V2

Charging battery pack: 600mAh/3.7V

Music play time: about 3 hours

Phone call time: about 5 hours

Charging Earbuds

Last 3 hours battery working time

LED indicators

Status

Red-Solid

Earbuds in Charging

Red-Off

Fully charged

Red-Solid means Earbuds is in Charging

Red-Off means Fully Charged

Provide 4 times full charges

Fast Charging

20 minutes charging can provide 1 hour music play

Battery pack can provide 4 x full charges for two wireless earbuds.

BOX Wireless Charging

Designed for the modern life, never be strangled by headphone cables.

Enjoy the convenience of wireless charging and free charging devices provided by airports, hotels, and cafe shops around the world.

(Wireless Charging Pad Not Included)

Waterproof

Waterproof for daily life (you cannot dip it into water), you can wear it on when showering, swimming, washing face, exposing in the rain, having a bath, but cannot dive.

Please note this when you swimming (as illustrate):

Above water

Underwater

Notes for signal transmission distance (as illustrate)

≤ 10m signal works normal

≥ 10m signal will be interrupted

Earbuds Warning!

1. Please do not place the product in an environment where the temperature is too low (above 45°C or below 0°C).

2. Do not dismantle or repair the earbuds under any circumstances, if necessary, please send the product to the seller for repair.

3. After the earbuds and the charger are soaked in the water, please dry them with a soft cloth or dry by airing. If soaking in sea water, rinse with fresh water and then dry it. Use it after 2 hours.

4. The earbuds and the BT devices will be disconnected if the distance between them is more than 10 meters.

5. Keep the device and accessories away from children and pets.

6. Since the BT signal cannot be transmitted underwater, swimming, diving will caused the signal intermittent or disconnected.

7. Do not put the earbuds into the washing machine.

Battery Warning!

1. The battery in the product may cause fire disaster or risk of chemical burning if mishandled.

2. You can only use specified charger for this product to charge your battery.

3. The discard of battery should obey local law, if possible please recycle it. Do not dispose it as household garbage, because it may cause a explosion.

4. Users are not allowed to take out or replace battery in the product unless there is a stipulation on user manual. It is very hazardous to do this, may cause a damage to product.

CE

FC

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- -

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.