
Size: 222.75(W) x 105(H)mm

FRONT SIDE





Package Contents

- 1(One) Pair Earcuffs (One) USB-Type C Charging Cable
- 1(One) Portable Charging Case
- 1(One) Instruction Manual

Specifications

Driver Diameter: 11 mm Impedance: 32 Ohms

Charging Time: <2 Hours Bluetooth Range: 32.8 Feet Indectorit Reagness 25 O Hz - 20 kHz
Frequency Response: 20 Hz - 20 kHz
Sensitivity: 98 d8 +/- 3 dB
Power Supply, Libon Battery 3.7V 30 mAh Per earculf
Total Playtime: 10 Hours

How to wear



Power On/Off

Press and hold the button of earcuffs for 3 seconds and the LED will flash. Power On

Press and hold the button of earcuffs for 5 seconds and the LED will be off

Pair the wireless earcuffs with your mobile device

- 1. Keep the distance between the earcuffs and mobile device within 32.8 feet
- Neep the distance between the earcurs and mobile device within 32.8 feet.
 De-activate the Bluetooth function on your mobile device.
 Put the earcuffs back to charging case before use.
 Take both earcuffs out from charging case and wait for 3 to 5 seconds for auto pairing. The earcuff has indicator blinking quickly in red and blue.
 Another earcuff will blinking slowly in blue when auto pairing is done successfully.

 Activate the Bustach for motion or your part of the property of the property of the purpose of t
- 4. Activate the Bluetooth function on your mobile device and select
- "EP-0722 TWS" from the list shown
- After pairing is successful, both earcuffs LED will blinking slowly in blue

*Attention: If the auto pairing is not successful, manual pairing between earcuffs is essential by following below procedures:

- Make sure the earcuffs are charged.
- De-activate the Bluetooth function on your mobile device. (if you had been paired
 the earcuffs to some other mobile device(s) nearby, please sure to de-activate those device(s) too).
- Nower on both earcuffs simultaneously by press and hold the button for 3 seconds and wait for 3 to 5 seconds for auto pairing. (Keep the Bluetooth function off on your mobile device before this operation.)
- A Activate the Bluetooth function on your mobile device and select "EP-0722 TWS" from the list shown.

 5. After pairing successfully, both earcuffs LED will be off.

Reconnect the wireless earcuffs to your mobile device

When powered on, the wireless earcuffs will automatically connect with the last

Disconnect the wireless earcuffs from your mobile device

Power off the wireless earcuffs; or Switch off the Bluetooth on your mobile phone; or Leave the earcuffs 60ft away from your mobile phone or further.

BACK SIDE

Answer / Reject a call

When receive a call, press the button once (on either earcuff) to accept the call, or answer the call normally via your mobile phone Press and hold the button 2 seconds to reject it.

End a call

To end the call, just press the button at any side of earcuff with Beep sound

Pause / Play Music: Press on Left or Right button. Go back to previous song: Double press on Left button.

Advance to next song: Double press on Right button. Voice Assistant: Press and hold on Left or Right button for 2 seconds

Charging your earcuffs

- 1. Open the charging case cover. Insert the earcuffs into the charging case.
- The earcuffs will start the charge automatically.
 LED indicator light of the earcuffs will be turned on when charging.
- 5. Once fully charged, the LED will be off.

Recharge Charging Case

- ⚠ For your safety, please always use appropriate 5V output charger/Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.
- Use the USB Type-C charging cable provided with the packaging.
 Connect the USB Type-C plug to USB Type-C charging port on the charging case, then connect the USB plug to a wall adapter to begin charging.
- 3. The LED on the charging case will be flashing during charge.
 4. Once fully charged, the LED will be stop flashing.
 5. The LED will be on during earcuffs is charging and will be off after fully charged.

You must select a qualified charger from a regular manufacturer You must charge the charging case and earcuffs if it has been not used for more than 6 months.



▲ CAUTION: The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.

If the wireless earcuffs cannot be paired with your device, please try the following:

Ensure that your earcuffs are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated.

If the wireless earcuffs will not turn on:

ke sure the earcuffs are fully charged. Make sure the protective stickers are removed from the earcuffs

Can I change the battery for the earcuffs and the charging case? The wireless earcuffs and the charging case use a built-in non-detachable battery which cannot be removed.

If the charging case cannot be recharged:

If you use a power outlet, ensure that the power supply is connected securely and the outlet works.

- $\ensuremath{\Delta}$ Safety instructions for the lithium battery and charging the product
- -The input voltage to the product is 5V 1A. -In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product. -Only charge the product at ambient temperatures between 10°C/50°F
- Do not heat above 70°C/158°F, eg. Do not expose to sunlight or throw into fire. -Switch off the product after use.

-Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this

-In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke developm

FCC Statement

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipme

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following

- · Recrient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver
- . Consult the dealer or experienced radio/ TV technician for help

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by 1616 Holdings, Inc. is under license. Other trademarks and trade names are those of their respective owners.



ITEM# EP-0722

Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in China

Keep all relevant information for future reference