

STL-RC1-IT

User Manual

Remote Layout

Function Buttons:

1. ANS SW
2. POW SW



Operation



Make sure you are within range of the vehicle before using the remote.

1. To use the answer back function, press ANS SW.
2. To use the Smart Function, enable the Smart Feature in the POW SW.
The smart function is enabled or disabled by the color of the LED when the POW SW is pressed.
 - Green : Smart features enabled
 - Red : Smart features disabled

Note: The exact behavior in response to each button press may vary depending on the vehicle. Consult the vehicle manual for more information.

Note: The key has an antenna for transmitting UHF signals and an antenna for receiving LF signals. Each model can transmit at either 433.92 MHz or 313.85 MHz. Depending on the frequency, the electronic components and software for RF antenna matching on the PCB are different.

Battery Replacement

If the battery needs to be replaced:

1. Use a hex wrench to loosen the screws.
2. Use a coin to separate the upper and lower cases.
3. Remove the battery and replace it with a CR2032H button battery.
4. Push the key shell parts together and screw in the Phillips

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Warning

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs/récepteurs exemptés de licence qui sont conformes aux flux RSS exemptés de licence d'innovation, sciences et développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

1. Cet appareil ne peut pas causer d'interférences.
2. Ce dispositif doit accepter toute interférence, y compris celle qui peut provoquer un fonctionnement indésirable du dispositif.