

USER MANUAL

Please read this manual thoroughly before using this product and keep it for future reference.

PACKING LIST



Projector



Remote




User Manual




Power Cable

NOTICE

Recommended





NOT Recommended



1


FUNCTION OVERVIEW




(Multimedia version)

2


QUICK START



1 Plug the power cord into an outlet



2 Press the power button to turn on the projector.



3 Select the correct input source to project your device.



4 Focus ring to get the best image performance.



5 Press the power button to turn off the projector.

3

INPUT SOURCE

Press on the there s no but ton on the projector remote to enter the interface of **input source**.


A. USB Connection



PROJECTOR CONNECTION



PROJECTION DISTANCE&SIZE



4

SPECIFICATION

Display technology	LCD	Light Source	LED
Power supply	AC 100-240V 50/60Hz	Resolution Supported	576i, 576P, 720i, 720P, 1080i, 1080P
Projection Distance	3.8FT-18FT (1.16M-5.5M)	Projection Screen	37" - 170"
Installation Type	Front/Rear/Ceiling	Aspect Ratio	4:3/16:9/Auto
Focus	Manual	Ports	HD In*1/USB2.0 Port*1/ AV In*1/Audio Out*1/
Speaker	3W/4ohm	Unit Net Weight	2.2 lb (1 kg)
Unit Dimension	6.45*6.3*6.77 inch	Audio Format Supported	MP2/MP3/PCM/FLAC/WMA
Photo Format Supported	BMP/JPG/PNG/ GIF/JPEG	Video Format Supported	AVI/MP4/MKV/FL/MOV/ RMVB/3GP/MPEG1/ MPEG2/H.264/XVID


5

TROUBLESHOOTING GUIDE

1. Blurry Image
* Adjust electronic focus/keystone.
* Projector and screen/wall must be in effective distance.
2. Remote unresponsive
* Make sure remote points at IR receiver directly.
* Do not cover IR receiver.
3. Up Side Down Images
Enter "Menu" on projector or remote to flip the projection image.

6

Projection mode/Bluetooth speaker



Indicator status is as below at the power button:

Standby mode: red light
Working mode: blue light
Speak mode: blue light

After short pressing the power button, the projector is on:

Enter speaker mode: In the working state, short press the power button to switch to speaker mode. After entering the speaker mode for 20 seconds, it will automatically enter the Bluetooth standby state
Exit speaker mode: In the speaker mode, short press the power button or any key on the remote control to exit speaker mode, and enter projection mode

7

70*100mm

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.