
70 mm


70 mm

70 mm

Transparent Speaker



Charging Voltage of Speaker: 5V/1A Maximum Audio Power: 5W Response Frequency: 70Hz~18KHz Bluetooth Version: 5.1 Bluetooth Distance: 10M Battery Capacity: 500mAh (3.7V) Charging Time: ≈2 hours Play Time: ≈3-4 hours (70% volume, light off)



Part Name

Power Switch
Type-C Charging Port
Mode Switch

Use Instructions

Charging:

Connect the Type-C charging cable to the charging port. The indicator light will turn red when charging begins. It will turn off when charging is completed.

Usage:

Press the power switch for 2 seconds to power on/off. Navigate to your device's Bluetooth menu. Connect to "25171." Once paired you will hear a beep. Tap the power switch to play/pause music, or to answer/end an incoming call.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules . Operation is subject to the following two conditions (1) This device may not cause harmful interference (2) This device must accept any interference received. including interference that may cause undesired operation The Bluetooth word mark and logos are registered trademark owned by Bluetooth SIG. Inc. and any use of such marks by NINGBO LEADER IMPORT AND EXPORT CO LTD is under license. Other trademarks and trade names are those of their respective owners. This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the device and receiver --Connect the device into an outlet on a circuit different

--Connect the device into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment