
65 mmx90mm

PDE



3-in-1 wireless charging station	 Applicable Devices: Samsung Galaxy S20/S20 Plus Samsung Galaxy S10/S10 Plus/S10e/ Note 10/Note 9/ Note 8 Samsung Galaxy S8/S8 Plus/ Note 8 Samsung Galaxy S7/S7 Edge/S6 Edge Plus/Note 5 Samsung Watches: Galaxy Watch 3 45mm/41mm, Active 2/1, Gear S3, Watch 46mm/42mm, etc. iPhone 12 Pro Max/12 Pro/12/se 2 /iPhone11 Pro Max/11 Pro /11/XS Max/ XS/XR/X8 Plus/8 More cell phones compatible with QI wireless charge. Apple Airpods 2, AirPods Pro (Need to match wireless charging case) Apple Watch SE/6/5/4/3/2; Not suitable for Apple Watch Series 1. Please Note: The Watch Wireless Charging Area supports Apple Watch only Please remove your phone case before charging if the thickness > 5 mm, or if the phone case makes your phone 	 size longer than 164 mm. 3. Only use certified QC 3.0 Charging Wall Adapter to charge the device, do not plug into computer USB port or any other non-certified USB port. 4. Place your qi-enabled device accurately in the wireless charging area when charging. 5. a QC3.0 adapter is required when charging 3 devices simultaneously or want to have a fast charging effect. 6. Make sure to disconnect the device from power when cleaning. 7. It is normal and safe to hear a humming noise when very close to the charger. It means that this wireless charger is 	 adjusting its temperature to achieve a more efficient charging speed. 8. If your device can not be fully charged, this may due to high environmental temperature, please recharge after the temperature is lowered. Our charger has temperature control to safe guard your device when charging. Q&A: If the LED light flashes and the wireless charging dock doesn't work how can I deal with this problem? 1. Make sure your device supports the Qi wireless charging function before using this wireless charger. Check if you use the QC3.0 adapter to charge the device. 	 -3. Test with other US -4. Check whether you comes with metal of and metal attachm LED flash and prevent of the equipment complies with exposure limits set forth for a environment. This equipment and operated with a minimum between the radiator and any PCC Warning This device complies with Pa FCC Rules. Operation is subj conditions: (1) This device may not caus and (2) this device must accer received, including interferent undesired operation. NOTE 1: This equipment has to comply with the limits for pursuant to part 15 of the FC

IMPORTANT SAFETY INSTRUCTIONS

Before Using the unit, please read the user manual carefully

* Do not store device in high-temperature environment, including heat caused by intense sunlight or other forms of heat. Do not place device in fire or other excessively hot environments. Exposure to fire or temperature above 212°F (100°C) may cause explosion. * Do not use the wireless charger in excess of its

output rating. Overloading outputs above rating may result in a risk of fire or injury to persons. * Do not expose the wireless charger to rain or snow.

* Do not modify, repair or disassemble the unity, if so, please contact the manufacturer.

Switch off the wireless charger when not in use. The wireless charger will automatically switch off when disconnected from its wall charger.

JSB cables.

your devices' case al objects. Magnetic nments will make an revent charging.

with the FCC RF radiation or an uncontrolled nent should be installed num distance of 20cm any part of your body.

Part 18 and Part 15 of the subject to the following two

ause harmful interference, ccept any interference erence that may cause

has been tested and found or a Class B digital device, FCC Rules. These limits

are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.