



# Use instruction

USED AA BATTERY(NOT INCL.)

- Thank you for choosing our toy R/C car. To ensure correct and enjoyable use, please read through the following use instruction and have enough understanding of the product before use.

## ⚠ CAUTION:


### ■ ELECTRICALLY OPERATED PRODUCT

Not recommended for children under 6 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

#### How to recharge the Battery pack?

1. If 5\*1.5V AA batteries are used (Not including), simply load in the batteries according to the polarity marks. (Picture 1)



#### Transmitter and Vehicle operation



#### Operations Tips:



1. Please make sure the power switch is in the ON position when you operate, and OFF position when not in use.
2. If the car direction goes left, please adjust Steering alignment Lever to right until the car goes straight.
3. If the car direction goes right, please adjust Steering alignment Lever to left until the car goes straight.

Steering alignment Lever



#### Battery and Antenna Installation-Transmitter and Vehicle

1. Install one 9V (Not including) battery with polarity(+/-) as shown inside battery compartment. (Picture 1)
2. Follow the arrowhead to close the remote control's battery cover.
3. Locate the antenna mount on the top of controller. Insert the antenna into the mount opening and rotate in a clockwise direction until snug. (Picture 2)
4. Install new batteries or fully charged rechargeable batteries into the battery compartment on the chassis.
5. Tighten battery door with a Philips head screwdriver.



#### How to play?

1. Install 5\*1.5V AA batteries inside the battery compartment that is underneath the chassis, taking care to observe the polarity. Fit back the cover.
2. Insert 9V battery inside the controller. The car is now ready to run.
3. Turn the two switches located on both the car and the controller to the "ON" position and then operate the car.
4. If the car does not run in a straight line, adjust the steering alignment lever located beneath the chassis.
5. When the light in the controller begins to dim, it may be time to replace the 9V battery.
6. When your R/C model car begins to lose performance, power or function, it may be time to recharge or replace the batteries.

#### Battery safety Information

1. Don't short-circuit terminals.
2. Don't recharge non-rechargeable batteries.
3. Different types of batteries or new and used batteries must not be mixed.
4. Dispose of batteries safely. Don't dispose of batteries in fire as they may explode.
5. The battery charger used should be regularly examined for damage to the cord, plug, enclosure and other parts. In the event of damage do not use it until it has been repaired.
6. Exhausted batteries are to be removed from the toy.
7. Keep these instructions for future reference; they contain important information.
8. Packaging has to be kept since it contains important information.

#### Care and Maintenance

1. Always remove batteries from the toy when it is not being used for a long period of time.
2. Wipe the toy gently with a clean damp cloth.
3. Keep the toy away from direct sunlight and/or direct heat.
4. Do not submerge the toy into water that can damage the electronic assemblies.



GUANGDONG CREATIVE DOUBLE STAR TECHNOLOGY CO.,LTD

Address: Yangdongpian industrial Area, Dongwan, Lianxia, Chenghai, Shantou, Guangdong, China.

TEL: 0086-754-85500487/85473487

FAX: 0086-754-85500487/85473487

E-MAIL: CDS@CDS-TOY.COM

WWW.CDS-TOY.COM



Open a Web page by phone scanning

## Instructions additional

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no guarantee that interference

will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference

by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.