

5.8厘米

8厘米



XG-15  
无线蓝牙耳机  
使用说明书

#### 产品示意图



#### 包装清单

真无线蓝牙耳机.....2对  
耳机充电仓.....1个  
Type-c 充电线.....1个  
说明书.....1个

#### 连接说明




首次使用时先将耳机放入充电仓，插上充电线，将耳机和充电仓充满。



#### 操作说明



1、打开充电仓盖取出耳机自动开机，会自动连接最近一次配对过的手机。



#### 基本参数

名称	XG-15
蓝牙版本	5.3+EDR
蓝牙距离	10米
待机时间	120小时
耳机充电时间	0.8小时
耳机电池容量	40mAh
充电仓电池容量	300mAh
充电仓充电	请使用5V-1A充电器充电

#### 产品特点

- 全新蓝牙5.3版本，更多无线高清体验
- 分离式机身设计，享受真无线立体声效
- 可充电式收纳盒收纳即可为耳机充电
- 采用高清数字显示，电量不用猜

#### 保修说明

尊敬的用户，您好！  
感谢您购买我们的产品，为了保证您的利益，请您在购买本产品后，仔细阅读说明书及以下内容：（下列情况不属于保修范围，本公司可提供有偿服务，敬请注意）

- 1、未按使用说明书操作、使用、保管，导致本产品故障和损坏。
- 2、擅自拆卸、篡改产品包装以及条形码。
- 3、擅自改动出厂设置和刷机操作。
- 4、意外因素或者人为导致产品损坏，如输入不合格的电压、真值、进水、碰撞、产品严重氧化或者生锈等。
- 5、因不可抗力，如地震、火灾、水灾、雷击等导致的故障和损坏。

#### 注意事项

- 长时间使用耳机可能会造成听力损伤，请合理安排使用时间
- 请勿使用不合格充电器和高压电流充电
- 请勿拆卸，避免因拆卸而造成产品损坏
- 请勿自行拆卸、修理或改造本产品
- 请勿使用化学溶剂擦拭本产品



XG-15  
True Wireless Earphone  
Usermanual

#### Product specification




#### Packing List

Wireless Earphone.....2pcs  
Charging case.....1pcs  
Type-C Charging Cable.....1pcs  
User Manual.....1pcs


#### Connection instructions




Please charge fully the charging case and earphones before the first time to use



#### Instructions



1. Open the charge case and take out the earphones, it will power on connected the last time paired phone automatically.



#### Basic parameters

Name	Minnini True Wireless Earphone
Chipset version	5.3+EDR
Work distance	10meters
Standby time	120H
Earphones Charging Time	0.8H
Talking time	4H
Earphones battery capacity	40Mah
Battery capacity of charging case	300Mah
Please use the 5V-1A charger for charging	

#### Product features

- New 5.3 version, more wireless HD experience.
- Separated fuselage design, enjoy true wireless stereo effect.
- Rechargeable storage box can charge the earphones.
- Using high-definition digital display, no need to guess the battery

#### Warranty description

Dear customer,  
Thank you for your patronage of our products, in order to ensure your interests, please carefully read the instructions and the following contents (the following conditions are not covered by the warranty, the company can provide paid services, please pay attention):

1. Failure to operate, use and keep the product in accordance with the operation instructions leads to failure and damage of the product.
2. Unauthorized graffiti, tear up the product packaging and bar code.
3. Unauthorized modification of factory Settings and dismantling repair.
4. Accidental factors or man-made product damage, such as input unqualified voltage, high temperature, water, damage, serious oxidation of the product or rust, etc.
5. Failure and damage caused by force majeure, such as earthquake, fire, flood, lightning strike, etc.

#### Notes

- It may cause hearing damage under longtime using, please arrange the use time reasonably.
- Do not use unqualified charger and high voltage current charging
- Do not throw, to avoid the product damage caused by falling
- Do not disassemble, repair or alter the product by yourself.
- Do not use chemical solvent to wipe the product.

## **FCC Requirement**

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.