


PetGrow-Smart Tape for Pet User Instruction



Display



	Low battery warning
	Bluetooth connection
cm/in	Measuring unit
0000	Measuring data

Charging Light

When the LED shows red light, it means the device is charging. After fully charged, the light turns off.

How to Use

- 1.Download the “PetGrow” APP, then register an account on the APP.
- 2.Enable the Bluetooth, and open the APP.
- 3.Turn on the Tape, and it will be connected to the APP automatically.
- 4.Select any “body part” on the App and then pull out the tape buckle to measure your pet.
- 5.Short press the tape retractable button, make sure the tape is as closely as possible to your pet's body part.
- 6.Short press the “M” button, the measuring data will be transmitted to the APP on your phone.
- 7.Click “Save” on the APP to keep the data after measurement.

Note: the Display will be dimmed if there is no any operation within 10 seconds, and turned off within 1 minute.

Technical Data

Accuracy	2‰	Measuring Range	1500mm/60in
Resolution	0.1cm/0.04in	Battery	150mAh
Measuring Unit	cm/in	Charging Port	TYPE-C
Working Temperature	0°C~40°C	Working Humidity	≤85%

Download the APP

1. For Android system, please search the key word "PetGrow" on Google Play.
2. For IOS system, please search the key word "PetGrow" on APP Store.



Bluetooth Connection

- 1.Turn on the device by short pressing the power button.
- 2.Turn on the Bluetooth on your phone and open the App.
- 3.The Bluetooth icon will be bright after the connection successfully.

Trouble Shooting

Problem	Possible Cause	Solution
After click the retractable button, it does not reset “zero” on the Display.	The retraction acts too fast.	Long press the power button and the “M” button at the same time to reset it to “zero”.
No data shows on the Display when pull out the tape.	System halted.	Reset the device. (Long press the power button for 13 seconds.)

Cautions



1. The product contains small accessories. Keep the product out of the reach of children to prevent swallowing.
2. Specified type of battery is required. The voltage of external power supply should meet the requirements, if not installed and used in accordance with the instructions, may cause damage or fire.
3. Do not disassemble, repair, or modify the device, otherwise, may cause damage to the product.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.