


Pantone Black C

# Cut Line



- charging the speaker lamp:
- The speaker lamp will require approximately 3 hours to fully charge. To charge, be sure to use the included USB-C cable. Plug the USB-C tip into the port of the speaker lamp. Plug the USB-A tip into a power supply of at least DC 5V 1A

4 in

warning: please use UL compliant power supply.

### troubleshootina:

- · If the speaker lamp is not working, charge the speaker lamp fully and try again.
- . If the speaker lamp is not working correctly, turn it on/off to restart.
- If the speaker lamp won't charge, make sure the supply works, is 5V 1A, and not damaged.
- . If the speaker lamp makes no sound or does not show as an available device, make sure it is not paired. If so, unpair the device and re-pair the desired device.

### safety:

- · Do not use near any water source
- · Do not modify or repair this device
- · Do not use in high temperatures or extreme weather
- · Do not use chemical detergents to clean your device, use a soft dry cloth
- Do not expose to fire or excessive temperatures, the operating temperature should not exceed 95°F (35°C)
- · Do not look directly at the light source to avoid harming your eyes
- · Children should be supervised when using these products

SAVE THESE INSTRUCTIONS

5.6 in

## room 🔨

FCC ID:2AO23-SPKL1 Style number: SPKL1 DPCI: 074-14-4291 Input: 5V=1A Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a reaidential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or Proverse, there is no guarantee that menterine will not occur in a particular instantion. In this equipment does cause naminu interference to ratio of television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reportent or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connext the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction. Target Corp. Mpls. MN, 55403 Phone: 1-800-440-0680

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at customersupport@gemsfindvours.com

front

back