



EUT Minimal transmission




Report No.: FR391101AO Page No. : 14 of 24











Report No.: FR391101AO Page No. : 16 of 24








EUT ceased transmission



Note: T1: AWGN signal is injected, T2: AWGN signal is removed.

Report No.: FR391101AO Page No. : 18 of 24






Note: T1: AWGN signal is injected, T2: AWGN signal is removed.

Report No.: FR391101AO Page No. : 19 of 24






Note: T1: AWGN signal is injected, T2: AWGN signal is removed.

Report No.: FR391101AO Page No. : 20 of 24






Note: T1: AWGN signal is injected, T2: AWGN signal is removed.

Report No.: FR391101AO Page No. : 21 of 24






Note: T1: AWGN signal is injected, T2: AWGN signal is removed.


Report No.: FR391101AO Page No. : 22 of 24





Note: T1: AWGN signal is injected, T2: AWGN signal is removed.

Report No.: FR391101AO Page No. : 23 of 24




Note: T1: AWGN signal is injected, T2: AWGN signal is removed.

Report No.: FR391101AO Page No. : 24 of 24




Adapter mode



2: Over Limit (dB) = Level (dBuV) - Limit Line (dBuV).

: 1 of 4 Report No.: FR391101AO Page No.






Report No.: FR391101AO Page No. : 2 of 4



POE mode




Note 1: Level (dBuV) = Read Level (dBuV) + LISN Factor (dB) + Cable Loss (dB) + Aux (dB).

2: Over Limit (dB) = Level (dBuV) - Limit Line (dBuV).

Report No.: FR391101AO Page No. : 3 of 4





Report No.: FR391101AO Page No. : 4 of