# TRUE WIRELESS EARBUDS USER MANUAL

## Resetting your TWS

If your TWS won't pair to each other, place them back in the charging case. When you pick up them and it will auto-pair.

# **FUNCTIONS**

#### Power on

- 1.Remove your earbuds from the charging case to auto Power On.
- 2.Or touch the R or L earbud for 4 seconds to Hear a prompt tone.

## Power Off

- $\ensuremath{\mathsf{1.Place}}$  your earbuds back into the charging case
- 2.Or touch the R or L earbud for 5 seconds to hear a prompt tone.

#### Answer

Touch R or L 2 times

## **End Call**

Touch R or L 2 times

# Rejecting a call

Touch and hold R or L earbud 2 seconds until hear a prompt sound

# Play/Pause

Touch R or L earbud 2 times

#### Next song

Touch R earbud 3 times

# Previous song

Touch L earbud 3 times

## Summoning Siri

Touch and hold R or L earbud 2 seconds until

hear a prompt sound

# BLUETOOTH PAIRING INSTRUCTION

- 1.Remove both earbuds from the charging case. They will begin auto-pairing to each other. You will hear 2 beeps and a prompt tone to confirm a successful pairing.
- 2.Keep the earbuds within 3 feet of your smart device(for Bluetooth pairing only). Enable your device's Bluetooth function from your device's settings menu. Select "Canyon BT headset"from the Bluetooth device list to pair the earbuds to your device.
- 3. You will hear a prompt tone indicating that TWS are now ready to use.
- 4.Each earbud can be used independently.

# CHARGING

(Be sure fully charge the TWS before using for

The first time)

## Charging the case:

Low battery indication: the WHITE LED light on the bottom of the case flashes 4 seconds then turn off.

Plug the Type-c cable into the bottom of the case to charge it.

The LED will flash green while charging. Once fully charged, LED will glow solid green.

# Charging the earbuds:

When the earbuds are in low power, you will hear "battery low" and red LED light will flash twice.

Place the earbuds into their respective slots in the charging case.

The LED light will turn to solid red while charging. The LED light on the bottom of the case will light on for 4 seconds and then off. Once fully charged, the LED on earbuds and case will turn off.

## SPECIFICATIONS

Input 5V-400mA Battery capacity 40mAhx2(earbuds):

500mAh(charging case)
Playtime(Varies by volume) 7.5 hours(totally 38

hours with the charging case)

Frequency response 20Hz-20KHz
Bluetooth version V5.3
Bluetooth range 10m/33ft

- 1. Don't expose to liquids
- 2. For AC/DC Adapter, the socket-outlet shall

be installed near the equipment and shall be easily accessible. We recommend users charge CANYON BT headset with DC 5V/400mA adaptor.



- 3. To prevent possible hearing damage, do not listen at high volume levels of long periods.
- 4. There are no restriction of use

### FCC STATEMENT

This device compiles with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications to this unit not expressly approved by the party responsible for compilance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference but one or more of the followine measures:

- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
  -- Connect the equipment into an outlet on a circuit different from
- -- Connect the equipment into an outlet on a circuit different fro that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

  Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.



