Product user manual xTRG MK-I

1. Battery

The product requires two CR123A batteries for power.

2, switch the machine

Press the button to turn on the machine when it is powered off. Press the button to turn off the machine when it is powered on.

3. BLE communication

Service UUID: 0xFFF0

Communication UUID: Receives 0xFFF1, sends 0xFFF2

4. Signal flow

After connecting to the local device, the host sends a byte 0x00 to the local device every 2 seconds, and the local device returns DC 6V

To the host computer, which?? Is the battery voltage of the device, the unit is 0.1 volts.

Note: If the device does not receive the data sent by the host computer within 6 seconds, the connection will be disconnected.

When the target surface of the device is HIT by the laser, the device sends "HIT=?? \r\n "to the host computer, where?? forHit position.

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.