

EDIFIER®



HECATE EDF700012 (GX07)

TRUE WIRELESS GAMING EARBUDS WITH ACTIVE NOISE CANCELLATION

Download EDIFIER CONNECT APP from the APP store/Google Play Store

■ Product description and accessories



Accessories:


Ear tips x 2 pairs, Storage bag x1, Brand sticker x1, Brand card x1, Charging cable x1

Note:

- There are different size of ear tips attached in the package, please select the suitable ones to wear.
- Images are for illustrative purposes only and may differ from the actual product.

■ Power on/off

- The earbuds will power on when the case is opened.
- The earbuds will power off when placed in the case and the case is closed.



The ice blue light flashes.

■ Charge

● Charge the earbuds

- Place the earbuds in the case and close the case for charging.

● Charge the charging case

- Connect the case to power source with the included charging cable for charging.
- Red light steady lit = charging
Red light off = fully charged

● Battery level indicator on the charging case

- Open the charging case to show its battery level:
ice blue light flashes three times at a normal speed: 66%~100%
ice blue light flashes twice at a normal speed: 33%~66%
ice blue light flashes once at a normal speed: 10%~33%
red light flashes rapidly: low battery level, please charge the case in time.



Input:

5V 200mA (earbuds)


5V 1A (charging case)

Battery level indicator (on both sides)

Warning: The rechargeable batteries that provide power for this product must be disposed properly for recycling. Do not dispose of batteries in fire to prevent an explosion.

■ User guide

● Bluetooth connection



- Place the earbuds in the case, press and hold the button on the case for around 3 seconds to enter Bluetooth pairing, and the ice blue light and white light of the earbuds will flash alternately;
- Set mobile phone to search for and connect to "HECATE GX07", after pairing is successful, the white light will be steady lit in music mode and the ice blue light will be steady lit in game mode.

● TWS pairing of the left and right earbuds & clear pairing records

Place the earbuds in the case, double click the button on the case to enter the TWS pairing of the left and right earbuds and to clear pairing records, and the white light will flash rapidly; After pairing is successful, the earbuds will auto-enter Bluetooth pairing, and the ice blue light and white light of the earbuds will flash alternately.

■ User guide

● Functional operation



Accept/end a call: double click the left or right earbud



Noise cancellation mode switch: double click the left earbud



Sound mode switch: triple click the left earbud



Pause/play: double click the right earbud



Next track: triple click the right earbud

Note:

- Noise cancellation mode switch: noise cancellation mode on (unavailable for one earbud), noise cancellation mode off, ambient sound mode.
- Sound mode: game mode, music mode.

● Wearing detection function

- Music control: remove **the earbud** from ear to pause music;
- Noise cancellation control: insert the two earbuds to ears to turn on noise cancellation mode, and remove them to turn off noise cancellation mode.
- You can also set or close the wearing detection function via the EDIFIER CONNECT APP.

■ FAQs

When charging the charging case, the indicator is off.

- Please ensure the charging case is correctly connected with power source.

No sound

- Check if the earbuds are operating.
- Check if the earbuds volume are at an appropriate level.
- Check if the earbuds are correctly connected with mobile phone.
- Check if the earbuds are operating within a normal working range.

The call quality of the earbuds are not good.

- Check if mobile phone is in an area with strong signal.
- Please ensure the earbuds are within effective distance (10m) and no obstacle between the earbuds and mobile phone.

When playing music, cannot control pause/play/next track via the earbuds.

- Please ensure the paired device support AVRCP (Audio/Video Remote Control Profile) profile.

The tapping function is too sensitive or not sensitive.

- Please ensure you are tapping within the effective area with a moderate intensity or at an appropriate angle. You can also adjust to a desired tapping sensitivity via the EDIFIER CONNECT APP.

After one earbud alone is connected to another mobile phone, there is no sound from the other earbud when used again.

- When one earbud alone is connected to another mobile phone, the interconnection between the left and right earbuds may have been disconnected. To restore the two earbuds mode, double click the button on the case to resume interconnection between the left and right earbuds. Then try again.

There is a delay problem when playing game.

- Please triple click the left earbud to switch to game mode and then start playing game.

Wearing detection function is not sensitive or too sensitive.

- To ensure every wearing of the earbuds by user can be recognized, the recognition of wearing detection have been slightly raised. If they are not used, please place the earbuds back into the case for charging and storage; it is better not to place the earbuds alone in the pocket or on the desk for long periods of time, so as to avoid interference with the wearing detection function or missing of the earbuds. You can also set the automatic in-ear detection function to other functions or close it via the EDIFIER CONNECT APP.

■ Maintenance


- If it is not used for long periods of time, please charge the product with lithium battery every three months.
- Keep the product away from humid places to avoid affecting internal circuit. Do not use the product during intense exercise or with much sweat to prevent sweat from dropping into the product to make damage.
- Do not put the product in places exposed to sun or with high temperature. High temperature will shorten service life of electronic components, damage battery and make plastic components deformed.
- Do not put the product in cold places to avoid damaging internal circuit board.
- Do not dismantle the product. Non-professional personnel may damage the product.
- Do not drop, strongly vibrate, strike the product with hard object to avoid damaging internal circuit.
- Do not use drastic chemicals or cleaner to clean the product.
- Do not use sharp objects to scratch product surface to avoid damaging shell and affecting facade.

Model: EDF700012
FCC ID:Z9G-EDF144
IC:10004A-EDF144

Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong

www.hecategaming.com
Designed by DONGGUAN EDIFIER ESPORTS TECHNOLOGY CO., LTD.

www.edifier.com

 2020 Edifier International Limited. All rights reserved.

Printed in China

NOTICE:

For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.

Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

EDIFIER®

FCC Regulatory Compliance

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Compliance

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

ISED Regulatory compliance

This device contains licence-exempt transmitters that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

L'appareil ne doit pas produire de brouillage;

L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé.