

## Cloud Key Enterprise



## Mechanical

Dimensions	767 x 437 x 481.4 mm (31 x 17 x 19")
Weight	14.21 kg (31.3 lb)
Enclosure materials	Front panel: aluminum Chassis: SGCC steel
Mount material	SGCC steel rack mount

## Hardware

Processor	16-core Intel® Xeon®-5P Gold 5218L at 2.3GHz
Memory	(2) 16GB DDR4 ECC RDIMM
On-board storage	(1) 256GB, M.2 2280 SATA
Networking interface	(1) LAN: 1 GbE RJ45 port
SFP+ interface	(1) LAN: 20G SFP+ port
Management interface	Ethernet Bluetooth
Power method	(2) Universal AC input, 100–240V AC, 7A max, 50/60 Hz
Power supply	(2) Hot-swappable AC/DC PSU, 550W
Supported voltage range	100–240V AC
LCM display	(1) 13" touchscreen Bootup animation; bootup in progress Firmware upgrade icon; firmware upgrading
Button	(1) Factory reset
Operating temperature	0 to 40° C (32 to 104° F)
Operating humidity	8–95% noncondensing
Certification	CE, FCC, IC

## LEDs

Ethernet	White: link/activity
SFP+	White: link

## FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

## ISED Canada

### CAN ICES-3(A)/NMB-3(A)

This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

### CAN ICES-3(A)/NMB-3(A)

Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. l'appareil ne doit pas produire de brouillage;
2. l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## RF Exposure Warning

The antennas used for this transmitter must be installed to provide a separation distance of at least 20(FCC/IC) cm from all persons and must not be located or operating in conjunction with any other antenna or transmitter.

Les antennes utilisées pour ce transmetteur doivent être installé en considérant une distance de séparation de toute personnes d'aumoins 20 (FCC/IC) cm et ne doivent pas être localisé ou utilisé en conflit avec tout autre antenne ou transmetteur.`