

Model BL39 Bluetooth earphone user manual Please read this guide carefully to ensure safety and satisfactory operation. Please keep this guide properly for future reference	Charging box Left headphone Right earphone Image: Charging cable x1 Image: Charging cable x1	Microphone/indicator light Function touch area Sound outlet	<image/> <image/> <image/>	20:51 ← Bluetooth Bluetooth Phone name Paired devices ∩ Bl.39 In use, for media Note: For headphones that have already been connected, removing them will automatically connect back to the device	Volume decrease: Double click left Previous song: Hold for 2 seconds to the left (L) Pause playback: Click on the (L/R) key Answer a call: Click on the (L/R) button while in the incoming state End call: Click on the (L/R) button for 2 seconds during the call Reject incoming call: Touch the (L/R) button for 2 seconds in incoming call mode Game mode: Connect to standby or listen to music for incoming calls, 4-tap touch (L/R) key Sleep mode: When selecting sleep timing, click the left and right ear (L/R) button to cycle through sleep timing (30 minutes/45 minutes/60 minutes) and select the playback duration. After the duration is completed, it will automatically shut down.
Operation mode (charging) Digital screen display The LR and four battery cells indicate the power level of the left and right headphones. When the headphones are inserted, the digital display will turn off after 15 seconds. When the headphones are in a charging state, the battery cell will flash: When the headphones are fully charged, the battery cell will display I: 0-25% normally II: 26-50% III51-75% IIII: 76-100% After the headphones are placed in the charging compartment, the digital display area will immediately display the current battery level of the charging compartment. When charging the charging compartment, the digital screen of the charging compartment lights up, the battery level will flash, and the display will be 100% when fully charged	Specification parametersWireless Bluetooth earphonesProduct modelBL39Bluetooth versionV5.3Battery typeRechargeable polymer carp batteryCharging inputDC 5V300ABattery capacityHeadphone 30mA charging box 300mAhRated voltage3.7VFrequency Response20Hz-20KHzCharging timeAbout 2H	Troubleshooting common problems:Problem phenomenonExclusion methodBarphones cannot be paired with phonesPlease check if the headphones are in pairing or reconnection mode, and if the Bluetooth search function of the phone is turned on. Delete/cancel the headphone name on the phone and follow the instructions to reconnectHeadphones cannot be turned onPlease check the battery level of the headphones And charge it first before attempting to turn it on.Disconnect the earphone from the phone at a distance of 10 metersDue to Bluetooth being a wireless connection technology that is sensitive to interference and obstacles between devices, please check the connection Is there any metal or other objects within the range that affect the connection	 Reminder When connecting for the first time, please control the distance between the headphones and the phone within 1 meter: After successful pairing, when the phone and the earphone are used in the future, when the Bluetooth of the phone is turned on, the earphone can be automatically connected to the phone when turned on The specifications and external form of this product may vary at any time due to improvements and enhancements The design and specifications are subject to change without prior notice. 5. Please use a cloth frequently to clean the headphones Matters needing attention Do not use this product while driving or cycling Do not use this product for long periods of time or at high volume to avoid hearing damage. Do not use this product in noisy environments (such as densely populated highways) to avoid danger. This product is not equipped with any self repairable parts, Do not dismantle or modify this product without authorization. Do 	<text><text><image/></text></text>	Warranty card Justooth headset 12 months from the date of purchase, the relevant accessories 3 months from the date of purchase. During the warranty card and shopping voucher to enjoy the free maintenance for any product quality-related failure Definitions conditions are not free for date of non-product parts , or tear, alter the label, security marks, etc. 9. Mange caused by force majeure, man-made damage, etc. 0. The mange caused by force majeure, man-made damage, etc. 0. Do not meet the performance fault listed in the Bluetooth Headset Performance Fault Table. 0. Due to human causes, this product and its accessories have gerformance faults listed in the Bluetooth Headset Performance Fault Table. Dustomer service information
Charging precautions Use a charger with an output voltage of DC 5V-1A, a USB port on a PC or a charger with USB port output (a charger that has been certified by a reputable manufacturer must be selected) Kind reminder This product includes a built-in rechargeable carp battery. Safety warnings for battery use: Do not hit, squeeze, or throw into the fire. If severe swelling occurs, please continue to use. Please avoid exposure to high temperatures: Do not use the battery after soaking in water. Please try to remove the battery from the headphones to avoid damaging them. Headphones will automatically consume power when left unused: It is recommended to charge the headphones within 3-6 months.	Music time5 hours (experimental data for reference only)Communication distance<10 metersmicrophone-42±3dBSupport ProtocolHSP, HFP, A2DP, AVRCPList of accessoriesBluetooth earphones * 1 set of Type-C charging cables * 1 user manual * 1The above data comes from the laboratory, and actual parameters may vary due to product or other factors	No sound when headphones are connected to computer devicesPlease check if the computer audio output device is a Bluetooth audio device and supports the A2DP protocol, and check the computer output volumeUnable to use headphones to control mobile applications after connectionIt is normal for different brands of phones or applications to have different settings, and some devices and programs do not support Bluetooth headphone control	not place or use it in high temperature or humid environments -Do not throw this product into fire or water -Do not place heavy objects or apply pressure on the headphones, as this may cause deformation during long-term storage -According to pediatric medical experts, it is not recommended for people under 9 years old to use earphone products -Magnetic fields may be harmful to people wearing pacemakers and defibrillators. It is recommended that patients who use pacemakers and implantable defibrillators maintain a distance of at least 3cm between this earphone and the implantable device -The product contains a built-in rechargeable battery. Safety warning for battery use: Do not disassemble, collide, squeeze, or put into fire. If there is severe swelling, do not continue to use, do not place in a	Bluetooth earphone performance fault table name Performance failure Image: Bluetooth headset 1. Bluetooth earphones cannot hear sound Bluetooth headset 1. Bluetooth earphones cannot hear sound Surving the call, the other party cannot hear sound 3. Unable to charge Bluetooth earphones or charging boxes 4. Button function malfunction 4. Button function malfunction	Customer nameContact numberContact addressProduct nameProduct modelDate of purchasedealerMaintenance date

PDF

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: •Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.