

Getting Started

Press and hold the Power Button until you hear the start-up tone. Go to Settings on your device and activate Bluetooth.

Search for and select either Narmony, Rocktopod, or AuROARa BEARealis in your device options. You will hear a tone as your pet pairs with your device.

Play music, snap pics, SPLASH, have fun! True Wireless Stereo Pairing (two Splash pets)

Select one of the pets to be the "lead" speaker by double clicking the Rlay/ Pause button to activate TWS. You will hear a successful pairing tone.

To disconnect the paired speakers, double-click either of the Play/Pause button.

Play/Pause Button

Press this button to pause or play audio. Press and hold to disconnect from your device. Volume Buttons @

The nand buttons control the volume and also allow you to skip forward to the next song or jump back to the previous song.

To skip to the next song, tap the button once; to jump back to the previous song, tap the button once. To increase the volume, press and hold the button; to decrease the volume press and hold the button.

Auto Shut-off Feature

After 10 minutes of inactivity, your speaker will power down automatically.

Low Battery Feature

When your battery is ready to be recharged, you will hear a tone 3 times every 30 seconds before the speaker turns off.

Selfie Mode

To switch to Selfie Mode, tap the Power Button. Your keyboard may be unavailable on your device while in this mode. Open the camera app on your device and press the

Power button to take a picture.

LED Lights

• Flashing Blue: The speaker is in Bluetooth device search mode.

 Solid Blue: Successfully paired with device.
 Solid Red: In charging mode; Light will turn off when speaker is fully charged. Your speaker will continue to operate while charging.



Troubleshooting I am having trouble connecting or using my speaker(s). What do I do?

Most problems can be solved with a simple Bluetooth reset. Turn off the speaker(s), turn off the Bluetooth on your device for 30 seconds

and then turn it back on. Turn on the speaker(s). Connect by selecting the speaker(s) on your Bluetooth list.

Splash pets are very loyal

If you are still unable to connect, you may need to disconnect the speaker from a previously paired device within Bluetooth range. Once disconnected, try to pair again with the new

I can only get one speaker to play. How do I pair two speakers to play in TWS mode?

Turn off the speakers, disconnect and forget them from your device, and follow the True Wireless Stereo Pairing instructions again. If you are still having difficulty, try the following:

- 1. Turn Bluetooth off, and then turn it on again. 2. Make sure both of the speakers(s) are completely disconnected from all previously
- connected Bluetooth devices. 3. Follow the True Wireless Stereo Pairing
- instructions 4. Connect to your Bluetooth device.

For any other information or assistance, please visit the support pages at MyAudioPet.com

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.