

Value=1 Pu	rple	Value=5 Gre	en		Second buttor
Value=2 Or	/alue=2 Orange Value=6 Blue				Group 5
Value=3 Cy	an				Third button h
(DEFAULT)	Third button re				
	Parameter 7 indicates LED Indicator Brightness, Choose the LED indicator Brightness level.				
size=1 byte Available settings: 0–10					(Dim Down)
Value=0 LE		s sectings, e			Fourth button
Value=1		ightness	Value=6	60% Brightness	Group 6 First b
Value=1 Value=2		rightness	Value=7	70% Brightness	Group 7 Secor
Value=2 Value=3		rightness	Value=7 Value=8	80% Brightness	Group 8 Third
Value=4		rightness	Value=9	90% Brightness	Group 9 Fourth
Value=4 Value=5		rightness	Value=7 Value=10	100% Brightness	Command Cla
		ngnuness	value-10	100% bigittless	Generic Device
(DEFAULT): 5					Specific Device
Scene Con					Command Clo
This remote supports four scene controls					0x5E - COMMA
Scene 1 : First Button			1-Tap/2-Tap/3-Tap/Held/Released		0x85 - COMMA
Scene 2 : Second Button			ap/2-Tap/3-Tap	0x8E - COMMA	
Scene 3 : Third Button		on 1-Te	ap/2-Tap/3-Tap	0x59 - COMMA	
Scene 4 : Fourth Button 1-Tap/2-Tap/3-Tap/Held/Released					0x55 - COMMA
Association Group:					0x86 - COMMA
This remote supports 9 Association Group controls					0x72 - COMMA
Support gr	0x5A - COMMA				
Each group	0x73 - COMMA				
Group 1 Life	0x80 - COMMA				
Group 2 First button press 1x send basic set 0xff, Second button press 1x send basic set 0x00.					0x9F - COMMA
Group 3 Third button press 1x send basic set 0xff, Fourth button press 1x send basic set 0x00.					0x5B - COMMA
Group 4					0x87 - COMMA
First button hold more than 0.5s send SWITCH_MULTI - LEVEL_START_LEVEL_CHANGE(Dim Up)					0x70 - COMMA
First button release send SWITCH_MULTILEVEL_STOP_LEVEL_CHANGE					0x84 - COMMA
Second button hold more than 0.5s send SWITCH_MULTI - LEVEL_START_LEVEL_CHANGE(Dim					0x6C - COMM/
	Down)				

on release send SWITCH MULTILEVEL STOP LEVEL CHANGE

hold more than 0.5s send SWITCH\_MULTI - LEVEL\_START\_LEVEL\_CHANGE(Dim Up) release send SWITCH\_MULTILEVEL\_STOP\_LEVEL\_CHANGE hold more than 0.5s send SWITCH\_MULTI - LEVEL\_START\_LEVEL\_CHANGE

release send SWITCH\_MULTILEVEL\_STOP\_LEVEL\_CHANGE button press 1x to toggle on/off (send basic set 0xff or 0x00). and button press 1x to toggle on/off (send basic set 0xff or 0x00). d button press 1x to toggle on/off (send basic set 0xff or 0x00). rth button press 1x to toggle on/off (send basic set 0xff or 0x00). Class

ice Class:0x18 - WALL\_CONTROLLER ce Class:0x00 - NOT\_USED

Classes:

MAND\_CLASS\_ZWAVEPLUS\_INFO AND\_CLASS\_ASSOCIATION AND\_CLASS\_MULTI\_CHANNEL\_ASSOCIATION AND\_CLASS\_ASSOCIATION\_GRP\_INFO MAND\_CLASS\_TRANSPORT\_SERVICE IAND\_CLASS\_MANUFACTURER\_SPECIFIC AND\_CLASS\_DEVICE\_RESET\_LOCALLY IAND\_CLASS\_POWERLEVEL AND CLASS BATTERY AND\_CLASS\_SECURITY\_2 /AND\_CLASS\_CENTRAL\_SCENE

IAND\_CLASS\_INDICATOR AND\_CLASS\_CONFIGURATION

MAND\_CLASS\_WAKE\_UP MAND\_CLASS\_SUPERVISION

MAND CLASS FIRMWARE UPDATE MD

## FCC warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference,

(2) This device must accept any interference received, including interference that may cause undesired operation, changes or modifications not expressly approved by the party responsible fo compliance could void the user's authority to operate the equipment.

#### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, 2. Read and follow all instructions that are on the product or provided with the product. pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection 3. do not use an extension cord. against harmful interference in a residential installation. This equipment generates, uses and can 4. Reference the National Electrical Code, NFPA 70, specifically for the installation of wiring radiate radio frequency energy and, if not installed and used in accordance with the instructions, andclearances from power and lighting conductors. may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interfer-5. Installation work and electrical wiring must be done by qualified person(s) in accordance ence to radio or television reception, which can be determined by turning the equipment off and with allapplicable codes and standards, including fire-rated construction. on, the user is encouraged to try to correct the interference by one or more of the following meas- 6. do not install or use within 10 feet of a pool 7. do not use in a bathroom ures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is

- Consult the dealer or an experienced radio/TV technician for help.

# CAUTION - PLEASE READ!

receiver is connected.

This device is intended for installation in accordance with the National Electric Code and local circuit over current protection. regulations in the United States, or the Canadian Electrical Code and local regulations in Canada. SAVE THESE INSTRUCTIONS -. This manual contains important safety and If you are unsure or uncomfortable about performing this installation consult a qualified electrician. operating instructions.

Parameter 2 indicates the	low battery alarm report. Use it to set battery levels for low battery
reports.	
size=1 byte Available rang	e : 5%-20%
(DEFAULT) : 5%	
Parameter 3 LED indicate: activation).	s Indicator Color for the First button of remote control (Scene 1
Choose the LED indicator	color for the First button of remote control triggers.
size=1 byte Available settir	ıgs: 06
Value=0 White	Value=4 Red
Value=1 Purple	Value=5 Green
Value=2 Orange	Value=6 Blue
Value=3 Cyan (DEFAULT) : 0	
Parameter 4 LED indicate	s Indicator Color for the Second button of remote control (Scene 2
activation). Choose the LE	D indicator color for the Second button of remote control triggers.
size=1 byte Available settir	ngs: 06
Value=0 White	Value=4 Red
Value=1 Purple	Value=5 Green
Value=2 Orange	Value=6 Blue
Value=3 Cyan	
(DEFAULT) : 1	
Parameter 5 indicates LEE	) Indicator Color for the Third button of remote control (Scene 3
activation). Choose the Ll	ED indicator color for the Thrid button of remote control triggers.
size=1 byte Available settir	ıgs: 06
Value=0 White	Value=4 Red
Value=1 Purple	Value=5 Green
Value=2 Orange	Value=6 Blue
Value=3 Cyan	
(DEFAULT) : 2	
Parameter 6 indicates LEE	) Indicator Color for the Fourth button of remote control (Scene 4
	D indicator color for the Fourth button of remote control triggers.
size=1 byte Available settir	5
Value=0 White	Value=4 Red

## MEDICAL EQUIPMENT

Please DO NOT use this plug to control Medical or Life Support equipment. This device should never be used to control the On/Off status of Medical and/or Life Support equipment.

#### OTHER WARNINGS

Risk of Fire / Risk of Electrical Shock / Risk of Burns

### IMPORTANT SAFETY INSTRUCTIONS

1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

#### 8. WARNING:

Risk of Electric Shock

When used outdoors, install only to a covered Class A GFCI protected receptacle that is

weatherproof with the power unit connected to the receptacle. If one is not provided, contact a qualified electrician for proper installation. Ensure that the power unit andcord do not interfer

with completely closing the receptacle cover.

9. WARNING:

Risk of Electric Shock. Mount the unit at a height greater than 1 foot from the ground surface

### 10.WARNING:

Risk of Electric fire. install only to a receptacle protected by 20A branch