

# **Q6 MAX WIRELESS MECHANICAL KEYBOARD OVERVIEW**



#### Windows





- (1) Bluetooth indicator
- 2 2.4 GHz indicator
- 3 G Cable BT (Mode Toggle)
- 4 Win/Android Mac/iOS (OS Toggle)
- ⑤ Type-C Port
- 6 Battery Indicator

# **DEFAULT KEY LAYOUT:**

LAYER 0: This layer will be activated when your keyboard's system toggle is switched to Mac.



Layer 1: This layer will be activated when your keyboard's system toggle is switched to Mac and press the fn/MO(1) key.



LAYER 2: This layer will be activated when your keyboard's system toggle is switched to Windows.



LWin = Left Windows LAlt = Left Alt RWin = Right Windows RAlt = Right Alt RCtl = Right Ctrl

LAYER 3: This layer will be activated when your keyboard's system toggle is switched to Windows and press the fn/MO(3) key.



# **KEY DESCRIPTION**

Key Description		Key Description		Key Description	
Scr-	Screen Brightness Decrease	RGBMd-	RGB Mode Previous	Sat+	Saturation Increase
Scr+	Screen Brightness Increase	Hue+	Hue Increase	Sat-	Saturation Decrease
Bright-	Backlight Decrease	Hue-	Hue Decrease	2.4G	2.4 GHz Host
Bright+	Backlight Increase	RGB SPI	RGB Speed Increase	Batt	Battery life
Prvs	Previous	RGB SPD	RGB Speed Decrease	NKRO	N-key rollover
Play	Play/Pause	MO(1)	Layer 1 will be activated when holding this key		
Next	Next	MO(2)	Layer 2 will be activated when holding this key		
Mute	Mute	MO(3)	Layer 3 will be activated when holding this key		
Vol-	Volume Decrease	MO(4)	Layer 4 will be activated when holding this key		
Vol+	Volume Increase	BTH1	Bluetooth Host 1		
RGB Toggle	Turn Backlight on/off	BTH2	Bluetooth Host 2		
RGBMd+	RGB Mode Next	втн3	Bluetooth Host 3		

### LED STATUS OVERVIEW

LED Location	Function	Status
Battery Indicator	Charging	Charging - Static Red Fully charged - Static Green Low power- Slow Blinking
Bluetooth / 2.4 GHz Indicator	Bluetooth / 2.4 GHz	Reconnecting - Fast Blinking Paired - Light off Pairing - Slow Blinking
Caps Lock Indicator	Caps Lock	Enable Caps Lock - Static White Disable Caps Lock - Light Off

# FUNCTION DESCRIPTION: CHARGING

Plug the cable into a USB port and plug the other end into the keyboard port. Charging Indicator: A red light will stay on while charging; Fully charged in around 5 hours, a green battery indicator will appear. If the power is low, the red light will blink.

\*The Keychron keyboard is compatible with all USB ports. Please use a 5V 1A adapter or USB 3.0 for the best performance. The Keychron Q6 Max can be charged in 2.4 GHz/Cable/Bluetooth mode.

\*\*This product supports up to 5V charging voltage and 1A charging current. We are not responsible for any problems caused by improper charging.

# 2.4 GHZ / BLUETOOTH / WIRED MODE (MODE TOGGLE SWITCH) 2.4 GHZ WIRED MODE

- 1. Connect the 2.4 GHz receiver to your device's USB Port.
- 2. Switch the toggle switch to the 2.4 GHz option. The keyboard will automatically connect to your device.

\*Press the key combination "fn" + "4" to enter the forced pairing mode. During this period, it is recommended that the keyboard be within 20cm of the receiver.

#### WIRED MODE

- 1. Switch the toggle switch to the Cable option (it only works when a USB cable is plugged in).
- 2. Connect our cable with your PC and keyboard.
- 3. Backlighting will be turned on.
- \*Under Wired Mode, keyboard will not enter into Battery Saver Mode.

#### **BLUETOOTH MODE**

- 1. Switch the toggle switch to the Bluetooth option.
- 2. Backlighting will be turned on.
- 3. Hold "fn+1" key for 4 seconds to activate Bluetooth pairing (the Bluetooth indicator fast flashes for 3 minutes to detect pairing).
- 4. Search for the Bluetooth device "Keychron Q6 Max" on your device and connect it (the Bluetooth indicator goes off after successful pairing).

Note: This keyboard supports pairing up to 3 devices simultaneously via key combination "fn" + "1" / "fn" + "2" / "fn" + "3".

\*The Bluetooth indicator will continue to flash for 3 minutes.

\*\*Slow or failed connections may exist due to different Bluetooth versions, please make sure all the settings are correct.

#### SWITCH BLUETOOTH DEVICES

Short press key combination "fn" + "1" / "fn" + "2" / "fn" + "3" to switch to other device.

#### **RECONNECT:**

- 1. Switch the keyboard to the Bluetooth option to activate the keyboard.
- 2. The Bluetooth indicator flashes for 4 seconds and automatically pairs with the last paired device.
- 3. If the Bluetooth indicator is off, press any button to enter the connection again.
- \*The keyboard must have been paired with the device to perform this function.

#### TURN OFF THE KEYBOARD

Switch the keyboard to the Cable option and unplug the power cable.

#### **BACKLIGHT SETTING**

- Short press key combination "fn" + "tab" or "fn" + "knob (press)" to turn the backlight on/off.
- Short press key combination "fn" + "Q" / "fn" + "A" to switch between different types of lighting effects.

#### OS TOGGLE SWITCH

#### 1 - MAC/iOS

Switch the toggle to Mac/iOS when the keyboard is connected to a Mac or iOS operating system.

#### 2 - WINDOWS/ANDROID

Switch the toggle to Windows/Android when the keyboard is connected to a Windows or Android operating system.

\*When using the Windows/Android mode, 🔳 🖈 keys are used for "Windows" and "Alt" functions.

#### **TROUBLESHOOTING**

If unable to pair keyboard to device, confirm that the device you're trying to pair with is Bluetooth-capable. If so, restart the device and try pairing it with the keyboard again.

Note: On a Windows computer, a new Bluetooth connection will sometimes require additional software updates—a process that may still be ongoing after a message appears indicating a successful completion. Wait at least 20 minutes after pairing to make sure all updates are completed before restarting the computer.

Confirm that the device is configured to accept Bluetooth connections (Windows) and supports an external keyboard (HID profile).

Go to Bluetooth Devices > Open Settings and select the following: Allow Bluetooth devices to find this computer Allow Bluetooth devices to connect to this computer Alert me when a Bluetooth device wants to connect

### My keyboard isn't working in Bluetooth mode.

For the computer/smartphone:

Go to your device Bluetooth settings>Select the keyboard and remove/delete/unpair it.

Then restart your device.

For the keyboard:

Turn the keyboard off and back on. Then reconnect it to your device.

#### Wireless connection is interrupted even within 10 meters.

Check if the keyboard is resting on a metal surface that can iinterfere with the wireless signal.

## Third-party input tools are not compatible with the keyboard.

Due to compatibility, versions, brands and drivers of Windows/Android OS, functions of third-party input tools may be affected while using the keyboard. Please make sure your operating system and drivers are up to date.

## Certain multimedia keys or function keys do not work.

Functions of certain multimedia keys may be disabled due to compatibility, versions, brands, and drivers of devices.

\*Multimedia keys: ⑤/※/匂り/闘/辿/ベン/ベリ/ロ/ロ/切/切

Function keys: F1 / F2 / F3 / F4 / F5 / F6 / F7 / F8 / F9 / F10 / F11 / F12

## **Safety Precaution:**

Keep the product, accessories and packaging parts out of the reach of children to prevent any accidents and choking hazards.

Always keep the product dry to avoid corrosion.

Do not expose the product to extreme temperatures below -10°C(5°F) or above 50°C(131°F) to preserve the lifespan of the keyboard.

# Keychron, Inc.

# Dover, DE 19901, United States

Find us at:

https://www.keychron.com

Support@keychron.com

**f** @keychron

@keychron

**y** @keychronMK

Designed by Keychron

Made in China

this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications to this unit not expressly approved by the party responsible for compliance could

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)

void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.
- This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.



**(Keychron** Q6 Max 无线机械键盘 〔旋钮版本〕

# 完全组装版本

#### 键盘

1x 已组装成品键盘

#### 包含

1x 铝合金金属外壳

#### 1x PCB

1x PC定位板

1x PCB与定位板夹心吸音泡棉

#### 1x IXPE垫

1x PET垫

1x 乳胶底垫

1x 底壳吸音泡棉

1x 底壳PET垫

16x Gaskets缓冲垫(12个缓冲垫已安装 在键盘本体、4个放置在包装内部)

8套PCB卫星轴

1套键帽(PBT材质-双色注塑)

1套机械轴体

#### 线材

1x Type-C to Type-C 接口线材 1x Type-A to Type-C 转接头

1x接收器延长器

#### 接收器

1x Type-A 2.4 GHz 接收器


#### 工具

1x 拔轴键器

1x 十字螺丝刀

1x 内六角螺丝刀





# 套件版本

#### 键盘

1x 键盘本体(不包含键帽、轴体)

#### 包含

1x 铝合金金属外壳

#### 1x PCB

1x PC定位板

1x PCB与定位板夹心吸音泡棉

1x IXPE垫

1x PET垫

1x 乳胶底垫

1x 底壳吸音泡棉

1x 底壳PET垫

16x Gaskets缓冲垫(12个缓冲垫已安装 在键盘本体、4个放置在包装内部) 8套PCB卫星轴

#### 线材

1x Type-C to Type-C 接口线材 1x Type-A to Type-C 转接头 1x接收器延长器

#### 接收器


1x Type-A 2.4 GHz 接收器


#### 工目

1x 拔轴键器

1x 十字螺丝刀

1x 内六角螺丝刀






# 快速上手指南

如果你是Windows用户,请在包装盒里找到如下的键帽,用拔键器拔下键盘上的对应键帽并且更换。

## Mac / Windows



## 1 系统切换

请确保键盘左上角的系统拨片切换到对应系统,如果没有选择正确,

部分功能将无法使用。



# 2 连接2.4 GHz接收器


将2.4 GHz接收器连接到设备USB端口。



把开关拨到2.4 GHz模式 Switch toggle to 2.4 GHz mode



G = 2.4 GHz





注意:为了获得最佳的无线体验,我们建议将2.4 GHz接收器插入线材+赠送的接收器延长器,放置在书桌上靠近你的键盘,以降低延迟率和更少的干扰信号。


# 3 连接蓝牙



把开关拨到蓝牙模式 Switch toggle to Bluetooth



长按fn+1四秒使键盘进入配对模式, 键盘的配对名为: Keychron Q6 Max。



# 4 连接有线





# 把开关拨到有线模式



# 5 关于VIA映射软件

可以访问 usevia.app使用在线VIA软件, VIA是可以映射按键的软件。 如果VIA软件不能识别你的键盘, 请联系我们以获得技术支持。



- \*在线VIA只能在最新版本的Chrome, Edge和Opera浏览器中运行。
- \*VIA仅在键盘通过线连接到计算机时有效。

#### 6 关于键盘键层说明

键盘有四层按键设置。 层0和层1是用于Mac系统。 层2和层3是用于Windows系统。



如果您的系统拨片切换到Mac档位, 层0将被激活。



如果您的系统拨片切换到Windows,那么层2将被激活。 如果您在Windows系统模式下使用, 请对层2进行更改,而不是层0。 否则无法进行按键映射操作。

