


英

MONSTER



Monster Airmars XKT18

Wireless Gaming Headphones
instruction manual

Product parameters	
Bluetooth version	V5.3
Transmission distance	>10m
Driver diameter	413mm
Driver impedance	32Ω±15%
Sensitivity	-107.22±3dB
Frequency response	20Hz-20kHz
Battery capacity (charging case)	400mAh 3.7V
Battery capacity (headphone)	35mAh 3.7V
Charging time (charging case)	≈1.5 hours
Music playtime (headphone)	≈5.5 hours
Music playtime with charging case	≈22 hours
Packing list	
	Headphone*2
	charging case*1
	Charging base*1
	TX Connector adapter*1
	2.4G Bluetooth TX connector*1
	Type-C charging cable*1
	Instructions Manual*1

Product Schematic Description	
	Indicator light Multi-function button (MFB)
	Microphone pick up hole Battery compartment charging indicator
Connect the charging case to the 5V power adapter with Type-C charging cable.	
	Rated input: 5V=80mA (Headphone) / Rated input: 5V=380mA (charging case)
Tips: When the ice blue indicator flashes while closing the cover, please charge in time.	
	Rated input: 5V=1A (Charging base)

Indicator guide		
Mode	Description	Voice prompt
Power on	Headphone ice blue indicator flash for 1 second	*"Power on"
Power off	The orange light of the headphone flashes three times to turn off	*"Power off"
Pairing	Headphone ice blue light The orange light flashes alternately	*"Pairing"
Connected	Headphone indicator off	*"Connected"
Disconnected	The orange light of the headphone flashes three times to turn off The other headset turns off the light	*"Disconnected"
Low Battery	The orange indicator blinks once every 30 seconds	*"Battery Low"
Headphones placed in charging case	The ice blue light will light up in 1 second, 3 in seconds, it goes off, headphones are fully charged, Charging case light off	—
Charging case low power	The ice blue light of the charging case blinks rapidly for 5 seconds and then turns off	—
Charging case charged	Charging case ice blue light has been slow to breathe	—
Charging case fully charged	The ice blue light of the charging case is on for 10S and then extinguished	—
Product operating instructions		
1. Power on Method 1: Take out the headphones from charging case, the headphones will turn on automatically. Method 2: Long press MFB for 3 seconds.		
2. Power off Method 1: Put the headphones into the charging case and close the cover. Method 2: After disconnected from the bluetooth device for 3 minutes.		
3. Pairing Step 1: Take out the headphones from the charging case, the headphones will start pairing automatically. Step 2: Search and click for "Monster Airmars XKT18" on the bluetooth list of the smart device, and when connection is successful, "Connected" will be heard.		

* If the distance is exceeded, return to the effective distance within 3 minutes after disconnection, and automatically connect the device	
	Note: * If the product is not suitable for a long time, it should be fully charged and ensure that the device is in a shutdown state. * After charging, please pull out the charging cable to avoid equipment damage caused by long-time charging.
Dual mode connection	
2.4G Bluetooth TX connector	
	The headphone can switch between music and gaming modes (via a wireless connector or Bluetooth).
	TX pair connection: Plug in the TX, switch the headset to game mode, and connect successfully. The factory headset and TX require binding and pairing. (Note: Music mode and game mode, users can only use one connection mode at the same time)
	TX status call: In the TX working state, voice calls need to be picked up through the headset MIC. In the working state, voice calls need to be picked up through the headset MIC.

TX call back	In the headset and TX overdistance, or after the headset is turned on, it needs to be able to quickly connect back, TX is in the power supply state, to continue to keep the connection state.
TX Manual disconnect	Manually unplug TX, Automatically switch the music connection mode;
Touch key operation	
(Normal)	Voice assistant: Press the left MFB for 2 seconds Volume +: Click right MFB Volume -: Click left MFB
(Music mode)	Pause/Play: Double click Left/Right MFB Last song: Triple click left MFB Next song: Triple click right MFB
(Phone)	Answer: Double click the left/right MFB Reject: Press left/right MFB for 2 seconds Hang up: Double click the left/right MFB
(Game mode/Music mode switch: Device connected)	Press right MFB for 2 seconds to enter Game mode Press right MFB for 2 seconds to enter Music mode

Precautions

1. Headphone will turn on automatically (needless to press any button) pair and connect the device when the charging case is opened, After placing the headphone in the charging case, they will turn off and automatic charging will start when the cover is closed.

2. Charging every 15 days will extend battery life when not in use often. Cleaning off dirt on the charging contacts by cotton swabs with alcohol will maintain a good contact for charging.

3. Battery (Battery pack or battery combination) Do not expose to lighting, baking or similar overheating environment. Do not disassemble, impact, squeeze or put into fire. Do not continue to use if severe swelling occurs. Do not place in high temperature environment. Do not use after soaking in water.

4. Due to the wireless connection mode of this product, in the daily use process, influenced by the environment, mobile phone brand, usage behavior and other factors, it is normal that there may be a brief and slight sound delay in the process of playing music.

Warnings

1. Do not use headphones at high volume for an extended period of time.

2. Keep the headphones away from dust and water.

3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.

4. Keep headphones away from any impact or vibration.

5. Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts	Hazardous substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	O	O	O	O	O	O
Loudspeakers	O	O	O	O	O	O
PCBA	X	O	O	O	O	O
Accessories	X	O	O	O	O	O

This table is compiled according to SJ/T 11364.

O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

FCC Statement	
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.	
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) this device must accept any interference received, including interference that may cause undesired operation.	
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.	
FCC ID: 2A8PV-QSMXKT18	
Environment Friendly Use Period (EFUP)	
The period of use of this symbol (10 years) is the period during which harmful substances in electronic and electrical products will not leak or mutate under normal use conditions, and users of electronic products will not cause serious pollution to the environment or serious damage to their personal and property when using this electronic product.	

Warranty service	
Dear user, this warranty card is the proof of your future warranty application with the seller to fill it out and keep it for future use!	
User information	
User name	Email
Contact number	Postal code
Mailing address	
Product information	
Product name	Product number
Product barcode/Serial number/Batch number	
Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	
M MONSTER Certificate of approval Product No: _____ Production Time: _____ QC: _____	