


## Pairing Bluetooth® Receiver:



- (A) Place the Bluetooth module into the Bluetooth Slot.
- (B) Activate Bluetooth on the mobile device and bring it within the reception range.
- (C) Press and hold the Bluetooth Power Button for 3-5 seconds until the indicator alternately flashes blue and red to denote the receiver is now ready to be paired.
- (D) If the indicator doesn't light on, repeat by press and hold for 3-5 seconds until the indicator alternately flashes blue and red.
- (E) Enter "0000" when prompted to enter a PIN code.
- (F) Once paired and the connection is made, the indicator will alternately flash blue.
- (G) To disable the pairing, press & hold Bluetooth Power Button for 3 seconds, and the indicator dims.
- (H) For changing the connected device, power off and on the Bluetooth receiver again. Repeat the directions in "Pairing Bluetooth Receiver" to connect a different device. If the indicator alternately flashes blue and red, it denotes it's under the pairing status.
- (I) Pairing Bluetooth for two devices (Enable TWS Mode):  
Turn on one device first and operate steps A~F, then turn on the other one and do step C. Press the Bluetooth button twice for each device, during blue/red indicator light flashing intermittently, two Bluetooth receivers will pair automatically. Once paired, the blue indicator light will flash intermittently or stay on. Now play the music from the paired smartphone and get stereo sound amplification.

## Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

## FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0.5 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 0.5 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.