

Tablet



Model: GATA31012



Start Here

Exterior Features

Power On

Press and hold the power button to power on. Device will boot up

During use, press and hold the power button for about 5 seconds to power off, a system window Power Off will appear.
Select "power off" followed by


"ok." Device will shut down.


Sleep Mode

Tap the Power button to

NOTE:

- ▲ Please make sure to fully charge your device before powering on.
- ▲For Spanish users, go to "Settings" -"System" - "Language & input", then go to "Language" to enter "Language preferences", then click "Add a language", then choose "Español", then choose your regions, then, on "Language preferences" interface, press and move your language to the first place.





- Front Camera
- Volume up 2 Touchscreen
- USB Type-C
- 8 Volume down Power Button
- 4 Micro SD Slot
- Reset Button
- **5** Earphone port **11** Speaker
- 6 Rear Camera

What's in the box

- Tablet
- Quick Start Guide
- Power Adapter
- 4 Warranty Book

Caution: The AC adapter included with your device was specifically designed and approved for your model. Utilization of an after-market adapter may damage eit your device or other devices connected to it. If damage is determined to have been caused by utilization of an unauthorized power supply, it will not be protected

FCC regulatory conformance:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.