

SAFETY INFORMATION GUIDE

DOC20210407

Table of Contents

About the Manual 03

Warnings 03

Safety Information 05

Battery & Charger 09

FCC Regulations 11

I. Part 15 Compliance Statement 11

II. RF Exposure Information (SAR) 13

III. Hearing aid compatibility (HAC) 16

Disclaimer..... 19

About the Manual

The purpose of this Safety Information Guide (SIG) is to help you learn safe ways to use your mobile phone device and avoid serious and unsafe situations which could cause possible harm and injury.

Warnings

General Warning: You alone are responsible for how you use your phone and any consequences of its use and/or misuse. You must always switch off your phone when use of a phone is prohibited, such as in flight (with the exception of Airplane Mode, when permitted). Use of your phone is subject to safety measures designed to protect users and their environment.

Do not violate the following important instructions since violation may result in serious injury.

Do Not:

- Try to remove the non-removable battery from the device.
- Place your device in a microwave, which could lead to an explosion.
- Store your phone at temperature less than 14°F (-10°C) or more than 113°F (45°C).
- Expose your mobile phone device to open flames.
- Disassemble or attempt to repair your device. Instead, use an authorized service center.

Safety Information

The following information is for your safety only.

Do Not:

- Wash or expose your mobile phone to various liquids.
- Use your device in high humidity conditions for a long period.
- Drop, throw or bend your phone.
- Use harsh chemicals, cleaning solvents or aerosols to clean your phone.
→ In such a case, to clean, only use a soft, lint-free cloth and avoid excessive wiping. Remember to unplug all power sources, devices, and cables.
- Dispose of your old device in typical trash containers. Instead, follow local regulations on how to dispose of electronic products.
- Allow your pet to use your device as a toy and bite into it as it may cause electric shock or fire.
- Set the volume too high as it may cause hearing injuries.

Safety Information

- Use your device near a gas station as it may cause sparks that may cause a possibility of fire.
- Use the device if the device overheats and feels too warm. In such a case, turn off your device. Let it cool before using it again.
- Leave your mobile phone device in a hot car for a prolonged period of time, as the overheated device may cause battery issues, fire or explosion.
- Store your device while plugged in when it is not in use for a prolonged period of time.
- Turn on the device if the device is accidentally dropped in water. In such a case, turn off your device, dry your device with a clean dry cloth; leave the device to dry for at least 48 hours before use.
- Use the device if the display glass is broken, which can cause injury to skin.
- Use an unapproved charging adapter and cable; use the charging cable and adapter that was provided with your device.
- Insert the USB cable into the charging port if the cable pins are damaged.
- Use your device near a medical device such

as a defibrillator, as the radio frequency in the device may interfere with its function.

Safety for Children:

Keep your phone and its accessories away from the reach of small children. Do not allow children to play with the phone, its parts or accessories, because they can injure themselves or others. Your phone contains small parts and sharp edges which can detach and become a safety hazard for children, including a choking hazard. Seek immediate medical attention if an accessory, part, or battery is swallowed.

Transportation Safety Warning:

- Please observe all transportation laws and regulations. DO NOT TEXT AND DRIVE.
- Do not use your device at a gas station, near fuels or chemicals where there is a risk of fire and/or explosion.
- On an aircraft, using electronic devices may interfere with the aircraft’s electronic naviga-

- tional instruments. Make sure the device is turned off during takeoff and landing.
- Use caution when making calls in heavy traffic or hazardous weather conditions such as rain, sleet, snow, ice, and heavy traffic.

Battery & Charger

This phone contains a Lithium-ion polymer battery. Improper handling of the battery pack may present a risk of fire and burn. Do not attempt to open the battery pack yourself. Do not disassemble, crush, puncture, short-circuit the external contacts, dispose of in fire or water, or expose the battery pack to temperatures higher than 140°F (60°C). To replace the battery, take the device to an authorized service center. Recycle or dispose of the device according to local regulations.



Take extra precautions:

- Do not disassemble or open, crush, bend or deform, puncture or shred.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.

- Only use the battery with the charging system that has been qualified per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Only use an authorized service provider to replace the battery.
- Only dispose of the device in accordance with local regulations for consumer electronic waste.
- Avoid dropping the phone. If the phone is dropped, especially on a hard surface, and the user suspects damage to the phone, take it to a service center for inspection.
- Improper battery use may result in a fire, explosion or other hazard.

This product should be operated only with the following designated power supply unit(s).
Travel charger: Input: 100-240V, 50/60Hz, 0.35A.
Output: 5V, 2A.

