


Model: ITSBL-547-KBG

USER MANUAL

Product overview







Function Introductions:

- •When the unit is connected with power, Turn on the Power.
- •This Motion Lamp is designed to operate in an average room temperature of 20C 25C (68-77F). It takes 2-3 hours to warm up Make sure the Motion Lamp is at room temperature before starting.
- •Keep the Motion Lamp away from extreme cold or warm temperatures such as heating or air conditioning vents.
- •The Motion Lamp operates at a very warm temperature. Place on a solid stationary, flat surface and keep out of reach of small children and pets. Avoid direct sunlight to prevent colours from fading and extreme overheating.
- •The colour hue of the wax will mellow after 2-3 uses. If the room temperature is high the wax may become small and float to the top of the vase due to overheating. If the temperature is low, it will stay in the bottom of the vase without floating, Wait until the room temperature is back to the designated range before restarting.
- •Use only fine glass cleaner and soft cloth to clean the surface. Always unplug before cleaning.
- •When Motion Lamp is in operation be sure not to move or shake it in order to avoid causing permanent damage.
- •Motion Lamp should never be heated up or cooled down artificially.
- •Before carrying check to see if the wax layer is completely flat and solidified.
- •The space at the top of the vase is provided for expansion. Do not break the seal of the cap to fill it with liquids or solids.
- •Use maximum 30 watt reflector bulb for bulb replacement. Variance in bulb size or wattage will produce unsatisfactory operation, fire or may break glass.
- •The lamp and reflector may be off centre during shipping, Please re-centre before plugging in the lamp.
- •Always use the original box for long periods of storage, do not freeze.
- •DO NOT INGEST.WARRANTY VOID.
- •Bluetooth: Turn on the power, waiting for connection, search the device name to connect, Then you can enjoy music from your device accordingly;
- •If using AUX, connect the oncluded AUX cable to the port on the side, Then connect the 3.5mm auxiliary jack at the other end of the cable to your device's audio jack.

ADULT NOVELTY PRODUCT, THIS IS NOT A TOY.

Specifications:

Light Bulb: E17 / 30W 120V Speaker Rated Power: 5W max

Sensitivity: ≤1%

Frequency Response: 100Hz-18KHz Product Size: 4.25x4.25x16.5inch Power: AC 120V / 60Hz Speaker: Ø45mm,4Ω 5W x 1

SNR: ≥85db

Bluetooth Version: V3.0

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.