


Camping COB Lantern With Power Bank And Wireless Charger Instruction Manual 92194



Features:

1. Wireless Charging Pad
2. SOS Flash Light
3. Lantern
4. Light Button
5. Wireless Charging button
6. USB output
7. LED Indicator
8. Micro-USB input
9. Wireless Charging Indicator

What's included:

- 1 x Power Bank Lantern
- 1 x 2-in-1 charging cable (see above diagram)
- 1 x Instruction Manual

Tech Specifications

- Capacity: 10000 mAh/3.7V/37Wh
- Micro-USB Input: DC 5V/2A
- USB Output: DC 5V/2A
- Wireless Output: 5V/1A

Instructions:

1. Charging the power bank:

- a. Charge the power bank fully before usage.
- b. Using 2-in-1 charging cable, insert the USB A port into a certified USB AC adapter or USB port of a computer, insert the 2-in-1 tip (the side with pins upwards) into power bank micro input. Then charge begins.
- c. When Charging LED Indicator will flash, Once all 4 LED are illuminating and stop flashing device is fully charged.

2. Lantern & Emergency Light:

- a. Press the Light Button(4) to turn on the lantern.
- b. If you continue to press the Light Button there are 4 light modes (100% Brightness, 50% Brightness, Red flashing emergency light, Light OFF).

3. Wireless Charging:

- a. Press the Wireless Charging Button(5) the Wireless Charging Indicator(9) will illuminate BLUE.
- b. Place wireless charging enabled device onto the Wireless Charging Pad(1), indicator will turn RED when charging a device.
- c. Press the Wireless Charging Button again to turn off the wireless charging mode.

4. Charging with USB Port:

- a. Connect the 2-in-1 cable to your mobile phone/device. If Android device, the tip with pins upwards; If iOS device, the tip without pins upwards. Connect the other end of the power bank output. Then charge begins.
- b. While the device is charging, the power bank LED indicator will show the current energy of the battery.

SAFETY PRECAUTIONS:

WARNING—When using this product, basic precautions should always be followed, including the following:

1. Read all the instructions before using the product.
2. Charge the power bank fully before initial use. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified.
7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
10. Have servicing performed by a qualified repair person using only identical replacement parts.
11. This will ensure that the safety of the product is maintained.
12. Do not overcharge Phone. Unit may get hot with excessive use. Remove Phone when it is fully charged. Never charge for more than 7 hours at a time.

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
- * Warning:
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: 2ANFN-92194

WIRELESS CHARGING ENABLED DEVICES:

iPhone 8/8Plus/X, Samsung Galaxy S8/S8+/S7/S7 Edge/S6/S6 Edge, Nokia Lumia 1020/920/928, HTC 8X, HTC Droid DNA, HTC Rround, HTC Incredible 4G LTE, Moto Droid Turbo, Motorola Moto 360 Smart Watch, Moto Droid Maxx, Droid Mini, Google Nexus 6/4/5/7 (2013), LG D1L, LG LTE2, LG G2 (Verizon), Blackberry Z30 (Verizon)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Warning Statements: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.

MADE IN CHINA