

BLUETOOTH HEADPHONE

MH22182

OPEN EAR HEADPHONES

AIR CONDUCTION SPORTS WIRELESS HEADPHONES

Please read this Quick Start Guide carefully and keep it for future use.

Earphone x 2 (left & right)
Charging Case
USB-C Charging Cable
Quick Start Guide and Warranty Letter

1

2

3

4

5

6

1. Earphone LED indicator

2. Earphone Multifunction Touch button (MFB)

3. Charging contacts

4. Vocal position

5. Charging compartment MFB button

6. USB-C charging interface

Open the charging case cover and the earphone will turn on automatically. Put the earphones into the charging case, close the lid, and the earphone will automatically turn off and charge.

Use the included USB-C charging cable to charge, and the charging case indicator shows the charging status. When the charging case is fully charged, the charging case indicator light is long on.

Open the charging case cover and the earphone will turn on automatically. For new device connection, please turn on your phone's Bluetooth and search for 'BUGANI BIO' for pairing, after the connection is successful, you will hear the system voice prompt.

Turn down the volume: While music is playing, press the touch-enabled multifunction button in your left earphone. Turn up the volume: While music is playing, press the touch-enabled multi-function button in your right earphone.

Answer/end a call: 2 taps (both left and right earphone can be operated).
Reject incoming calls: When a call comes in, press and hold for 2 seconds (both left and right earphone can be operated).

Play/pause music: Double-tap the touch-enabled multi-function button (operated by both left and right earphone).
Previous song: Connected mobile phone status, left earphone tap 3 times.
Next song: Connected mobile phone status, right earphone tap 3 times.

Take out the earphones, sit the BUGANI BIO behind your earphone and gently rotate it into a comfortable position to ensure the best wearing and sound experience.

When the earphone is connected to the mobile phone, press and hold for 2 seconds to wake up the voice assistant and operate both the left and right earphone.

Open the lid of the charging compartment (when the earphones are not taken out), press and hold the MFB button of the charging compartment for 3 seconds, clear the pairing record between the earphones and the mobile phone, and the white light of the charging compartment flashes 3 times.

封面

Mode	Description	Voice Prompt
Power On	White light flashes quickly	System tone
Power Off	The red light is solid and 2S is off	System tone
Pairing	White light flashes quickly	-
Connected	The white light is solid for 1S off	System tone
Charging case	When charging the case, the instructions on the charging case. The red light flashes slowly and when it is full, it is full and the red light is long on	-

* After removing the earphone from the charging case, there is no need to press any buttons, the left and right earphone will automatically connect and Automatically enter pairing mode.

*Please place the earphones in the correct position for charging.

*It is not recommended to replace the battery privately without permission.

*Batteries (battery packs or cell combinations) must not be exposed to lighting, baking, or similar excessive heat.

BUGANI products will furnish a replacement or repair any part which proves (upon inspection by BUGANI) to be defective under normal use within 12 months of the original purchase date. This warranty does not apply to appearance items, or accessories in the human damage caused by leaking batteries, it also does not apply to the product, or to any part thereof that has been damaged through misuse or negligence, improper installation, or operation. Furthermore, this warranty will become invalid, in the judgment of BUGANI products or any parts installed incorrectly, repaired or altered by other than BUGANI Service department. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation incidental or consequential damages or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

For service, warranty, or product information, please contact: with your order ID.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
FCC ID: 2AVD2-MH22182

70x95mm
80G双胶
专色+黑色印刷 风琴折