technician for help.

FCC Compliance Statement (For Power Adapter)

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference, and
 (2) This device must accept any interference received, including interference that may cause undesired operation.
 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Simplified EU Declaration of Conformity

Hereby, CubeNest declares that the radio equipment type 3-in-1 series is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://www.cubenest.eu.

X40 3-in-1 Fold Magnetic Wireless Charger



scan for multi-language user manual

Product Overview

The Premium X40 Fold is the most compact 3-in-1 wireless charger in the world, it's easy to carry for on the go and charge multiple devices anywhere.

In the Box

- Fold 3-in-1 Magnetic Wireless Charger
- Power Adapter (PD) 20 watts
- Nylon USB-C to C cable 1 meter
- Travel Case

Wireless Charger Parameters

Input: 5V=3A 9V=2.22A 12V=3A
Output: 3W/5W/7.5W/15W (Total 22W Max)
Weight: 195 g
Dimensions: 68 x 68 x 23 mm
Main Material: High-Grade Aluminium
Compatibility: Works with iPhone 14/Pro/Pro
Max/Plus, iPhone 13/Pro/Pro Max/ mini, iPhone
12/Pro/Pro Max/mini, AirPods Pro 2/Pro/3/2,
Apple Watch 8/Ultra/SE 2/7/6/5E/54/3/2/1.
Safety Protection: Over-current, Over-voltage,
Over-temperature, Short-circuit Protection

Steps to Use the Wireless Charger

- Wireless charging may not work properly if you have attached a thick case to your device.
- $1. \ \ Unfold \ the \ wireless \ charger \ to \ desired \ position.$
- 2. Connect power adapter to the wireless charger, the indicator LED lights up in blue.
- 3. Place your devices on the wireless charger to start charging, the indicator LED turns to red.
- 4. Remove your devices from the wireless charger after fully charged, the indicator LED lights off.

Warning Notifications

- DO NOT use uncertified power adapter or USB cable.
- \bullet DO NOT use the wireless charger outdoors or in damp areas.
- DO NOT place any metallic labels or any objects onto the wireless charger.
- DO NOT place near heated surface.
- Use in room temperatures.

Warranty Terms

The warranty begins on the date of purchase and expires after 24 months.

In order to avoid unnecessary inconvenience, we advise to consult the support section on

To get the product repaired or replaced, please contact CubeNest during the warranty period by email (support@cubenest.eu) and include the following details: email address, your name and address, telephone number, date and place of purchase, and detailed description of the problem. If the problem appears to be any defect due to faulty materials and/or workmanship occurs within the warranty period, CubeNest will make arrangements for service.

This warranty is only valid in the country where the product is purchased and is not transferable and does not extend to users other than the original purchaser.

Legal Information

The Apple, iPhone, Apple Watch, AirPods and MagSafe are trademarks of Apple Inc., registered in the U.S. and other countries.

FCC Compliance Statement (For Wireless Charger)

This device complies with Part 18 of the FCC Rules. NOTE: This equipment has been tested and found to comply with the limits for consumer device, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV