

**77S0**

**QUICK GUIDE**

**USER MANUAL**

## **FCC Warning Statement**

### **(Section 15.105)**

#### **FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/ TV technician for help.

### **(Section 15.21)**

CAUTION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

### **(Ref: Section 15.19)(a)(3)**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **(Ref: FCC 2.1091 & FCC 2.1093)**

#### **RF exposure warning**

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

## Table of Contents

|                                    |          |
|------------------------------------|----------|
| <b>1.Start up Screen .....</b>     | <b>4</b> |
| <b>2.Media.....</b>                | <b>4</b> |
| <b>3.Bluetooth.....</b>            | <b>5</b> |
| 3.1   Pairing with smartphone..... | 5        |
| 3.2   Phone settings.....          | 6        |
| <b>4.Software Update .....</b>     | <b>7</b> |
| <b>5.Vehicle Info.....</b>         | <b>8</b> |
| 5.1   Vehicle Alerts .....         | 8        |

## 1. Start-up Screen



## 2. Media



Press the media button to display sources.



You can choose the source selection.

### 3. Bluetooth

#### 3.1 Pairing with smartphone



Select settings.



Select link icon.



Select paired device list.



Make sure your phone Bluetooth is switched on.  
Select your phone from the available devices list.



Select pair.

## 3.2 Phone settings



Select phone.



You can change your phone settings.

#### 4. Software Update



Select settings.



Press the down button.



Select system information.



Select software update.



Select "yes" to perform software update.

## 5. Vehicle Info

### 5.1 Vehicle Alerts



Select settings.



Select vehicle icon.



Select vehicle alert.



You can enable/disable the display of some important vehicle alerts on the system.