

XN Universal Remote Keys User Manual

Overview :

XN Universal Remote Keys is suitable for vehicle and garage door which contains the Xhorse receiver.

Button Description:



Change battery :

First use or when the battery runs out need to change new battery, following steps:



1, Just pry the plastic cover upward.

<div data-bbox="306 215 541 546" data-label="Image"> </div> <p data-bbox="220 546 703 680">2, take the battery out and replace new one (Notes:the battery type is 2032 with 3 voltage,ensure the positive and negative of battery is correct)</p>	<p data-bbox="853 439 1214 470">3, install the key same as before</p>
---	---

Pairing method :

- 1)Pairing with vehicle: Referring to the corresponding vehicle models to match.
 - 2) Pairing with garage door: Press the “learn” button of receiver for 2-3 seconds, then you can see the receiver led light on, press your remote 4-5 time, after that, the receiver led light will continuous flashing, when it off, pairing successes. If failed to match the receiver, please repeat the above method.
- If you want to control both vehicle and garage, please separate the frequency.

CE statements:

Hereby, Shenzhen Xhorse Electronics Co., Ltd. declares that the radio equipment type XN of Universal Remote Keys is in compliance with Directive 2014/53/EU and RER 2017 (SI 2017/1206).

RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

RFID(433.920MHz) Max Pe.r.p. is -20.28dBm.

Health and safety information:

- The operating temperature of the product is -20~55℃.
- Contact with liquid: Do not expose the device to liquid or touch it with wet hands. Any damage caused by water may be irreparable.
- Children: Be very careful. A portable device is not designed for use by children. The product contains small parts that could be swallowed or cause choking.
- Do not ingest battery, Chemical Burn Hazard.

This product needs to be used with a button/button battery. If the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

Keep new and used batteries away from children.

If the battery compartment does not close securely, stop using the product and keep it away from children.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

FCC statements:

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.