



TURNING ON YOUR EARBUDS

METHOD 1: Remove your earbuds from the charging case.

METHOD 2: If the earbuds are not inside the charging case or turned off, touch the RIGHT or LEFT earbud for 5 seconds until the blue LEDs flicker and you hear "Power On".

TURNING OFF YOUR EARBUDS

METHOD 1: Place your earbuds back into the charging case.

METHOD 2: Touch your earbuds for 5 seconds until you hear "Power OFF".

BLUETOOTH PAIRING INSTRUCTIONS

FIRST: Remove both earbuds from the charging case. They will auto-pair to each other.

SECOND: Keep the earbuds within 3 feet of your smart device (for Bluetooth pairing only.) Enable your device's Bluetooth function from its Settings menu. Select "RT60" from the Bluetooth device list to pair the earbuds to your device.

Once paired, you will hear "Device Connected."

Your SoundPlay earbuds are now ready to use!

SINGLE EARBUD USAGE

Each earbud can be used independently.

CALLING/MUSIC

ANSWER/END CALL

Touch RIGHT or LEFT earbud 2 times

REJECTING A CALL

Touch and hold RIGHT or LEFT Earbud 2 seconds until you hear a prompt sound

PLAY/PAUSE

Touch RIGHT or LEFT earbud 2 times

NEXT SONG

Touch the RIGHT earbud 3 times

REWIND/PREVIOUS SONG

Touch the LEFT earbud 3 times

VOICE ASSISTANT

Touch and hold RIGHT or LEFT earbud for 2 seconds until you hear a prompt sound to activate the Voice Assistant/Siri function. This function may not work for all devices.

CHARGING THE EARBUDS

When the earbuds are low in power, you will hear "Battery Low". Place the earbuds into their respective slots in the charging case. They will automatically begin to charge. The LEDs will turn solid red while charging. The LED on the bottom of the case will turn white. Once fully charged, the LEDs on earbuds and bottom of the case will turn off.

Make sure to fully charge the earbuds prior to the first use.

CHARGING THE CASE

Plug the standard USB-C charging cable into the port on the case and connect the USB head to a USB power source, such as an AC wall adapter or computer. The LED will turn Red while charging. Once fully charged, LED will turn off.

IMPORTANT SAFEGUARDS

- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
- Do not expose the device to extremely high or low temperatures, as it may damage the battery.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit.
- Do not use this unit if it has been dropped or damaged in any way.

- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep this unit out of reach of children
- This unit is not a toy.

CUSTOMER SUPPORT

If you have any questions about your product we are here to help. Call or email us and a representative will be happy to assist you:
1-855-GO-TZUMI or **support@tzumi.com**

SPECIFICATIONS

Bluetooth Technology: Version 5.2
Battery (Earbuds): 35 mAh (x2); 3.7V
Battery (Charging Case): 500 mAh; 3.7V
Input Power Supply: 5V/0.4A
Earbuds Charging Time (Est): approx 1.5 hr
Charging Case Time (Est): approx 2 hrs
Music Playback Time: approx 6.5 hrs
Frequency: 20Hz-20KHz

BATTERY DISPOSAL:

This product contains a lithium polymer battery. Lithium polymer batteries are environmentally safe when fully discharged. Please refer to your local and state laws for battery disposal procedures.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

