
Connect to HDTV/Monitor

41 Processor

Adjusting the resolution of video output via VGA to HDTV or monitor

Follow the steps below to enable audio output when conneting the Byte Plus to a TV or audio devices.

1. Right click and choose "Graphics Properties" 2. Double click "Display" 3. Choose the desired "Resolution" and "Refresh Rate" to adjust the desired display on screen



AZULC®

Configuring Audio

Follow the steps below to adjust the video output when connecting the Byte Plus to a HDTV or monitor.

1. Access the sound settings via the system "Control Panel" 2. Under "Playback Devices", click the display device that corresponds with your audio compatible display 3. Click the "Set Default" button in the lower right hand corner 4. Click "OK" to exit the setup

Bin	Salact a plactack device below to modify its actions		Printers Advanced printer setup Mouse Orevice Manager vs To Go startup options settings for media or devices Play CDs or other media automatically
2			
3		NS-320312NA15 Intel SST Audio Device (WDM) Default Device	INS eattings Change what the power buttoms do ord when the computer wakes Change when the computer sleeps Choose a pow
*			ther items larger or smaller Adjust screen resolution monitor flicker (refresh rate)
			obility Center ily used mobility settings Adjust settings before giving a presentation



🖸 🕒 🐼 🤀 📿 Fanless Windows[®] Mini Desktop PC


Connect with us! @azulletech 🚻 🕤 💟 🗗 in 👂



Customer Service info@azulletech.com www.azulletech.com Tel: (786)233-6769

Byte Plus Quick Guide





against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons during the normal operations

The device is indoor use only

