# VENTION'

# True Wireless Bluetooth Earbuds Air A01

User Manual | VWS-E29



## Specifications

Model: NBM Bluetooth version: Bluetooth 5.3 Compatible Bluetooth profile: AVRCP/A2DP/HFP/HSP Supported codec: SBC/AAC Maximum communication range: ≤12 m Frequency band: 2402MHz-2480MHz Frequency range: 20Hz-20KHz Earbuds' battery capacity: 40mAh/0.148Wh Earbuds' input power: 5V=50mA Charging case's battery capacity: 320mAh/1.184Wh Charging case's input power: 5V--500mA Charging case's interface: USB-C Material: ABS

## Operating instructions

a. When the charging case opens, the earbuds power on.

#### 2. Pairing and connection

1) Earbuds are ready to pair right out of the charging case Note: If the pairing fails, please check whether the earbuds are fully charged and repeat the operation above.



2) Open the Bluetooth menu on your device. In the list of discovered

Bluetooth devices, tap or click your Vention A01.

Note: For the first-time pairing, please keep the pairing range within 1m. After the pairing is successful, the earbud automatically powers off when placed back in the case, and you can use either earbud



#### 3. Power off

· Manual power off

- Auto power off
   a. The earbuds will automatically power off after 5 minutes of not being connected.
- b. When the earbuds are not paired with the phone due to the long distance, it will automatically power off if it is not connected for more than 5 minutes.
- Earhuds automatically power off when placed back in the charging case with the lid closed.
- b. When it is connected and not playing any content, press and hold the multi-function button for 5 seconds to power off (left or right).



#### 4 Music mode



Play/Pause: Tap the multi-function button twice quickly (left or right)



FCC Warning

Skip backward: Press and hold the multi-function button on the left earbud for 2 seconds





Decline the call: Press and hold the multi-function button for 2 seconds (left or right) Answer a call: Tap the multi-function button twice quickly (left or right)

#### 6. Using the voice assist function

When the phone is on standby or playing music, tap the multi-function button 3 times (left or right) to activate your voice assistant. Tap the multi-function button 3 times (left or right) to stop the mobile device voice control.

### 7. Clear the Earbuds device list

When the earbuds are powered on (and the device's Bluetooth function is turned off), tap the multi-function button 5 times to clear the Bluetooth devices list.

# 8. Earbuds status lights:

System state	Light activity				
Pairing mode	Slowly pulses white and blue.				
Connection process completed	The indicator turns off.				
Place the earbuds back	The indicator lights up in white while charging, and turns off after charging is complete.				

## 9. Charging case digital display:

System state	Display activity				
During charging, when the lid of the charging case is closed	The digital display remains illuminate to show the battery level, and the battery bars on the left and right move vertically like a scrolling animation. Once fully charged, the display will turn off.				
Charging	The digital display remains illuminated to show the battery level, and the last digit of the battery level flashes.				
Charging is complete	The digital display shows "100%" for the battery level, then turns off.				
The remaining battery charge of the charging case is less than 20%	During charging, when the lid of the charging case is opened, the digital display flashes to show the batterylevel, and it turns off after 10 seconds.				

## Important safety instructions

Please read all instructions and warnings before using this product. Inappropriate use will cause damage to the product or personal safety.

1. Do not expose products containing batteries to excessive heat (e.g., from storage in direct sunlight, fire, or the like) do not store this produ in high temperature, strong light, and strong magnetic field environment on the place it in other harsh environments such as fire source. If your earbuds ever go into the water, please dry it naturally before using.

2. Improper use of the product can easily cause product damage or

Improper use of the product can easily cause product damage or may endanger personal and properly safety.
 If consumers violate the product instructions and use them improperly, the company will not bear any consequences or legal liability for personal and property damage.
 If the company is the product of the company of the company of the theory of the company of the theory of the company of the comp

# Declaration on toxic or hazardous substances and elements contained in electronic products

	Texic or Hazardous Substances or Elements							
Parts name	Lead	Mercury	Cadmium	Hexavalent chromium	Polybrominated biphenyls	Polybrominated diphenyl ethers		
	(Pb)	(Hg)	(Cd)	(Cn4)	(PBB)	(PBDE)		
PC8s	Х	0	0	0	0	0		
Ceramic Parts	Х	0	0	0	0	0		
IC Parts	Х	0	0	0	0	0		
Charging Cables	0	0	0	0	0	0		
Casing	0	0	0	0	0	0		

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(I) This device may not cause harmful interference, and (2) this device may tax accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful inter ference to radio condance with the instructions, may cause harmful inter ference to radio condannications. However, in the condannication of the condann

- neutration in addition the receiving antenna.

Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE 3: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**APPR** 

FCC ID: 2A7Z4-NBM

#### Contents















For warranty service or support, please contact Vention team: 

Parts name	Lead	Mercury	Cadmium	Hexavalent chromlum	Polybrominated biphenvis	Polybrominated diphenyl ethers
	(Pb)	(Hg)	(Cd)	(Cn4)	(PBB)	(PBDE)
PC8s	Х	0	0	0	0	0
Ceramic Parts	Х	0	0	0	0	0
IC Parts	Х	0	0	0	0	0
Charging Cables	0	0	0	0	0	0
Casing	0	0	0	0	0	0









2023/08/16

折叠尺寸: 70x90mm 展开尺寸: 90x350mm 材质: 157g哑粉纸 风琴折双面印刷

蓝色印刷: C100 M:0 Y:0 K:0 参考: Pantone Process Cyan C

# 宁波福茂通讯科技有限公司



品名 PART NAME	NBM系列蓝牙	耳机包装说	型号 PART MODEL	VWS-E29	
设计	Melissa	单位	mm	客戶代码	
DESIGNER	MElissa	UNIT	1111111	Client NO.	
校对		版本	A0	图号	
CHECK		REV		DWG.NO.	
核准		PAGE	1/1	更新	2023/08/16



