

*If you have questions or comments, contact us.
Pour toute question ou tout commentaire, nous contacter.
Si tiene dudas o comentarios, contáctenos.*

888-480-9885

**INSTRUCTION MANUAL
GUIDE D'UTILISATION
MANUAL DE INSTRUCCIONES**

INSTRUCTIVO DE OPERACIÓN, CENTROS DE SERVICIO Y PÓLIZA DE GARANTÍA. **ADVERTENCIA:** LEÁSE ESTE INSTRUCTIVO ANTES DE USAR EL PRODUCTO.

DEWALT®

190 9935 DW2

DEWALT Bluetooth Standard Earphones

**Auriculares Inalámbricos de Trabajo
Ecouteurs Sans Fil Pour Emplois**

Part No. DXMA1909935 © 2019 Stanley Black & Decker, Inc.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

DEWALT® and the DEWALT Logo are trademarks of the DEWALT Industrial Tool Co., or an affiliate thereof and are used under license. The yellow/black color scheme is a trademark for DEWALT power tools & accessories.

Manufactured by E-filiate Inc.
11321 White Rock Rd.
Rancho Cordova, CA 95742 USA

Made in China



Important Charging Notes

- Longest life and best performance can be obtained if a device is charged when the air temperature is between 65°F and 75°F (18° – 24°C). DO NOT charge a device in an air temperature below +40°F (+4.5°C), or above +105°F (+40.5°C). This is important and will prevent serious damage to the device.
- The earphones may become warm to the touch while charging. This is a normal condition, and does not indicate a problem. To facilitate the cooling of the earphones after use, avoid placing the earphones in a warm environment such as in a metal shed or an uninsulated trailer.
- If the earphones do not charge properly:
 - Check operation of the receptacle by plugging in a lamp or other appliance.
 - Check to see if the receptacle is connected to a light switch which turns the power off when you turn out the lights.
 - Move the earphones to a location where the surrounding air temperature is approximately 65°F – 75°F (18° – 24°C).
- Do not freeze or immerse the earphones in water or any other liquid.


⚠WARNING: Shock hazard. Don't allow any liquid to get inside the earphones. Electric shock may result.

⚠WARNING: Burn hazard. Do not submerge the earphones in any liquid or allow any liquid to enter the earphones. Never attempt to open the earphones for any reason. If the plastic housing of the earphones breaks or cracks, return it to a service center for recycling.


Controller Functions

- On/Off: Press and hold the  key to turn on/off.
- Pause: Press the  key to pause playback, and press the key again to resume playback.
- Volume increase: Tap the + key; volume reduction: Tap the - key.

Note that pressing and holding down the - key instead of tapping it will result in starting the current song or audio file from the beginning. Pressing and holding down the + key will result in advancing from one song or audio file to the next.

- Advance: press and hold the + key to move forward to the next track.
- Return: press and hold the - key to go back to the previous track.
- Answer/hang up: press the  key for two seconds and then release it.

Pairing Procedure

- Place the earphones within one meter of your phone or tablet during pairing.
- Power-on the earphones by pressing and holding the  key on the earphone controller until you see the indicator light alternately flash blue and red. Voice prompts will indicate pairing mode is enabled.
- Enable the Bluetooth function of your phone or tablet, search the Bluetooth devices and select "DEWALT Earphones 9935" for pairing and connection.
- After the earphones are successfully paired to your phone or tablet, the blue light on the earphones will blink slowly. Voice prompts will confirm pairing is successful. The pairing mode will be maintained for five minutes. If pairing and connection are unsuccessful beyond two minutes, the headset will automatically switch to stand-by mode.
- After pairing is completed, the earphones and your phone or tablet will recognize each other without pairing again.
- To remove the pairing connection, enter the Bluetooth settings of your phone or tablet. Select "DEWALT Earphones 9935" and select the "Forget" option.

Note that the Jobsite Wireless Earphones can pair on a max. of 3 devices. If you experience difficulty pairing a new device, remove a pairing connection from an existing device.

Storage Recommendations

- The best storage place is one that is cool and dry, away from direct sunlight and excess heat or cold.
- For long storage, it is recommended to store the earphones in a cool dry place for optimal results.

Lifetime Limited Warranty

In case of product failure, E-fillate Inc. will issue a replacement. DO NOT RETURN PRODUCT TO STORE. Instead, please call 888-480-9885, 8:30 a.m.-5:00 p.m. PT, Monday - Friday, or e-mail us using dewaltinfo@efilliate.com.

Products improperly used, abused or altered are not covered under policy.

Customer Service

We're here to help. If you have a problem with this product or have questions on how to use it, please contact us. You do not need to contact the retailer you purchased this product from. Please contact one of our service representatives, using the contact info listed above, before shipping merchandise to us. Please provide the product number, DXMA1909935, when contacting us.

11321 White Rock Road
Rancho Cordova, CA 95742 USA

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.