

The image is a product quick start guide for the BolaButty S311 Rock Stone. It features a teal background. At the top center is the BolaButty logo, which consists of a stylized 'B' icon followed by the text 'BolaButty'. Below the logo, the words 'QUICK START GUIDE' are written in large, bold, white capital letters with a pink outline. Underneath this, the model number 'S311' is displayed in pink text inside a light yellow rounded rectangle. The central focus is a large, light yellow, rounded square frame. Inside this frame, the words 'ROCK STONE' are written in large, bold, white capital letters with a pink outline. At the bottom of the page, a line of white text reads: 'Before operation, it is imperative to carefully peruse the instructional manual.'

- 1 -

Rock Stone Speaker x 1

Wall Charger Adaptor x 1

Quick Start Guide x 1

Produce Name	Bluetooth speaker
Charging Time	2 Hours
Connection Method	Bluetooth (TWS)
Waterproof Level	IPX7
Bluetooth Version	Bluetooth 5.3
Working Range	100ft (Up to 50ft in TWS mode)

- 3 -

- 4 -

**After-Sales Email:**  
support@bolabutty.com



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.