	1				
3260 Spectrum <i>Bluetooth</i> ® Earbuds	Overview Vol - / Next On/ Off Pause / replay Answer / Hang up Vol + / Previous	Microphone Recharging Port	<ul> <li>on in the settings of y</li> <li>2. Turn the earbuds on seconds. The indica enabled devices near When pairing, remain indicator light will go within 5 minutes.</li> <li>3. "GEMLINE EB" will a select "GEMLINE EB" will a select "GEMLINE EB" and the earbuds had device, the indicator pairing.</li> <li>5. When you want to pl disconnect the earbud</li> </ul>	he Bluetooth function has been turned your Bluetooth enabled device. by pressing the power button for 4 tor light will flash to detect Bluetooth r you and will enter pairing mode. In within 3 feet of the earbuds. The off if no Bluetooth devices are detected appear on the Bluetooth device list, " to establish pairing. If instructed to	<ul> <li>BUTTON CONTROL</li> <li>Pause / Play: Press the On/Off button once to pause the music, press again to play.</li> <li>On / Off: Press and hold the On/Off button to control the power of the earbuds.</li> <li>Vol + / Previous: Press and hold the + button for 2 seconds for the previous track. Press once to increase the volume.</li> <li>Vol - / Next: Press and hold the – button for 2 seconds for the next track. Press once to reduce the volume.</li> <li>Hands-free: Press On/Off button once to answer an incoming call. While on a call, press On/Off once to end the call.</li> <li>Redial last call: Press On/Off button twice to redial last number dialed on the connected mobile device.</li> <li>CHARGING THE EARBUDS</li> <li>1. When the battery is low, please charge via the included USB cable. The charging time is approximately 2 hours and provides up to 3 hours of continuous operation. Standby time is approximately 150 hours.</li> <li>2. The LED indicator light will be red during charging and will turn blue once it is fully charged.</li> </ul>
Front Cover	1 1 1 1 1	page 02		page 03	page 04
<ul> <li>Front Cover</li> <li>WARNING</li> <li>1. Do not disassemble, repair, or modify the earbuds.</li> <li>2. Do not place product in or near fire to avoid danger, as it uses a lithium battery.</li> <li>3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the earbuds.</li> <li>4. Keep the earbuds dry and do not store the earbuds in damp areas to avoid damage to the earbuds.</li> <li>5. Avoid dropping the earbuds as it may damage the product.</li> <li>KIND REMINDER</li> <li>1. To prolong the earbuds life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.</li> <li>2. When an error occurs with the earbuds, please turn off the earbuds and restart it to troubleshoot.</li> <li>3. When the earbuds power is low, the Bluetooth range may be affected. Please charge the earbuds to avoid disruptions during use.</li> </ul>	Unable to pair the earbuds with a mobile device 1. 2. a dra tu th time to time 1. The music stops from time to time 2. 2. 4. 3. 1. 4. 4. 2. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4.	page 02         TROUBLESHOOTING METHOD         I. Inspect whether the earbuds is searching or a Bluetooth enabled device to connect o. If not, restart the earbuds.         2. Difficulty in searching and connecting to desired device can be affected if multiple levices are equipped, turned on, and in ange for Bluetooth connectivity. Please urn off or disable the Bluetooth function on he other devices.         3. The power of the battery is insufficient, alease recharge the earbuds.         I. Inspect the distance between the earbuds and the Bluetooth transmission range.         I. Inspect if there is an obstacle between he earbuds and the Bluetooth enabled levice.         3. The power of the battery is insufficient, alease recharge the earbuds.	PROBLEM The sound is low or distorted The Bluetooth indicator light remains OFF PACKING • Bluetooth® Earbud • Silicone Earbud Cc • USB Charging Cat • Travel Case and C • User Manual	TROUBLESHOOTING METHOD         1. Inspect the volume of the connected earbuds or Bluetooth enabled device and adjust the volume as needed.         2. The power of the battery is insufficient, please recharge the earbuds.         1. The power of the battery is insufficient, please recharge the earbuds.         2. Restart the earbuds.         2. Restart the earbuds.         3. Restart the earbuds.	page 04         SPECIFICATION         Bluetooth Specifications : Bluetooth <sup>®</sup> version 4.2         Support profile: A2DP         Transmission distance: up to 2 m (This may vary based on environmental factors or the type of Bluetooth <sup>®</sup> device being used)         Built-in battery: 70mAh Lithium battery         USB Recharge voltage: DC 5V/500mA         Output power: 5mW         Frequency Response: 20Hz - 20KHz         Transmission Response: 2.4GHz - 2.48 GHz         The Bluetooth <sup>®</sup> word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may

cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1)this device may not cause interference, and(2) this device must accept any interference, includinginterference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables auxappareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :(1) l'appareil ne doit pas produire de brouillage, et(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre lefonctionnement.