

## SKYTAG Card User Manual



### Charge the SKYTAG card



- Connect the charging cable to the card for charging,
- Charge the Card for, at least, 2 hours, when using it for the first time
- The LED flashes when charging.
- When fully charged, the LED is always on.

### Enable pairing mode

- Press the button once. The LED is flashing, indicating that the card is ready for pairing.  
(Remark: The tag will turn OFF if not pair within 10 mins)
- From IOS device, launch Find My.
- Under “Items”, select Add Item.
- Select “Other Supported Item”. Your device will now search for “SKYTAG Card”
- As soon as you see “SKYTAG Card” display on your device, tap and follow the on-screen prompts to complete the pairing process.

### Factory reset

- Press the button 3 times and on the fourth time press and hold the button.
- A confirmation tone is heard.
- The LED is flashing. The Card is in pairing mode until it is paired.  
(Remark: The tag will turn OFF if not pair within 10 mins)

**Instructions for disabling**

- Press the button 2 times and on the third time press and hold the button.
- Press and hold the button for 5 secs. A confirmation beep can be heard. The LED shall turn off after a while. This will stop sharing the location of this card.

**How to find the serial number of SKYTAG Card**

In FindMy App

- Open the Find My app.
- Tap Items.
- Find the SKYTAG Card and tap the name of the SKYTAG Card.
- The serial number appears under the name.

On the SKYTAG Card.

- Find the serial number printed under the SKYTAG logo.

**CE Statement**

We declare that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

Our product does not contain the AC/DC adapter. You need to purchase a DC 5V/1A adaptor which compliance with the directive 2014/30/EU.

The adapter shall be installed near the equipment and shall be easily accessible.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.