

# Wireless Charger

## User Manual



This Wireless Charger will allow you to charge any wireless compatible smartphone or device without the need for a charge cable by simply placing it on top of the charge plate. Compatible with the wireless charging protocols as stipulated by the Wireless Power Consortium (WPC).

### Contents:

1. Wireless Charger
2. Micro USB Charging cable
3. User Manual

### Specifications:

Size: 63 x 63 x 12.6 mm

Number of coils: One

Power Rating: 5W

Input: 5V / 1.5A

Output: 5V / 1A

Conversion Efficiency:  $\geq 70\%$

### Directions of Use:

1. Using the supplied USB charge cable, plug the Micro USB connector into the rear of the wireless charger and then the standard USB connector into an approved AC power adapter.
2. When the power is turned on, the LED indicator will turn on in white color for 3s then turn off to show that the wireless charger is ready for use.

3. Place your wireless compatible device rear down onto the charger. When detected and positioned correctly the indicator will switch the white LED on and begin to charge your device.
4. When charging is complete remove your device and the LED indicator will turn off.

**Notes:**

**Correct Operation:** Use only for the purpose the product was designed. Misuse may cause fire, explosion or other dangers.

**Appropriate Devices:** Use only Approved AC power adapters with this device as inappropriate current may cause lower than expected charge rates.

**USB Cable:** The cable supplied with this wireless charger provides appropriate current and connectivity. When using a higher input current, please use an appropriate cable rated higher than 2.0 Amps.

**Cleanliness&Use:** Ensure that the charging platform is clean at all times. Sensitive equipment and other non-metals or electromagnetic items should not be placed on the charging base.

**Overheating:** If this should occur, please turn off the power to the charger and allow it to cool before attempting to charge again.

**Misuse&Tampering:** Keep device dry. Do not store or operate in extreme environments. Do not attempt to open, throw, hit or shake this device.

**Sensitive Electronic Devices:**

Manufacturers recommend keeping a minimum distance of 20cm between a wireless charging device and other sensitive devices. If there is any reason to suspect that interference occurs, please turn off the power immediately.

## **FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The distance between user and products should be no less than 20cm