
Bluetooth Wireless Shower Speaker



UICK START GUIDE

Bluetooth Wireless Shower Speaker



(A) Power On / Power Off	Series:NBSPKWTPRF-K03	
(B) Play / Pause	NBSPKWTPRF-Q03	
(C) Volume + / Next Track	NBSPKWTPRF-U03	
(D) Volume - / Previous Track	NBSPKWTPRF-W03	
(E) Answer/End/Reject Call		
(F) Microphone		
(G) Micro USB Port		
(H) Suction Cup		

OPERATING INSTRUCTIONS

Charging Shower Speaker

1. Remove the Micro USB Port(G) waterproof cover and insert the power cable.

 Plug the USB end into a computor port or any 5V charging socket.
When the speaker is charging, the LED indicator light will turn on red.
Once the speaker is fully charged, the LED indicator light will turn

Bluetooth pairing

off.

 Long Press the power button (A), there will be a "beep" and the LET light will blink blue indicate it is in pairing mode.
Search the bluetooth manu on your compatible device and select "Pool Party Speaker" to start connecting.
Once paired, the Shower Speaker will beep and the Bluetooth LED light will turn solid blue.

USING YOUR SPEAKERS

Long press the power button (A) : Power On /Power Off Short press the button (B) : Play /Pause Music Short press the button (C) : Next Track Long press the button (C) : Volume up Short press the button (D) : PreviousTrack Long press the button (D) : Volume down Short press the button (E): Answer / End the call Double click the button (E) : Redial the last call

Note:When speakers in pairing mode, it will power off in 5 minutes later after the speaker did not connected any devices.

LED LIGHT INDICATOR

Playing Music: Slow flashing LED Light Charging via Micro Cable: RED LED Light Device Connected: LED Light On

Full Charged: No LED Light (Light Off)

Specifications

Product: Bluetooth Wireless Shower Speaker Bluetooth Version: V5.0 Input : SV/500Ma Power Output: 3W Battery Charging Time: 1-2 hours Play Time: Up to 2-3 hours Rechargeable Battery: 3.7V/300mAh (Built-In)

REGULATORY NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be located or operated in conjunction with any other antenna or transmitter. FCC ID : 2AJXA-ROSPEAKER