

deal
worthy™

OPP
Wireless Speaker

Instruction
Manual


Package Contents

- OPP Speaker – 1
- Micro USB Charging Cable – 1

Compatibility

- Compatible with most mobile phones


OPP Speaker Instructions



- Power Button:**
- Switch the power button to turn on/off.

- AUX in:**
- The speaker will auto-switch to the Aux-in mode while connected to your aux cable.

- Charging:**
- A full charge requires approximately 2-3 hours.
 - Using the Micro USB cable provided, plug the Micro USB end into the speaker, plug the opposite end into a USB power supply of at least DC 5V 1A. The indicator light will light up when charging.
 - Charging is complete when the red light turns off.
- Warning: please use UL-compliant power supply



- Using:**
- Press: volume down Hold: prev. track
 - |< Press: pause/play Double press: redial Hold 10 Sec.: Bluetooth disconnect
 - + Press: volume up Hold: next track

- Pairing:**
- Switch the power button to 'on' position on side of the speaker.
 - The indicator light will quickly flash blue when it is ready to pair.
 - Use the Bluetooth settings on your device to pair with **Speaker 01**
 - When pairing is successful the indicator light will turn solid blue and there will be a chime.
 - The speaker will automatically reconnect to the device it was most recently paired to when you turn it on and it is in Bluetooth mode.

- Audio Indicators:**
- Ascending tones – power on
 - Three rapid tones – ready to pair
 - Two rapid dings – low battery
 - Two low tone – max volume
 - Quick descending tone – AUX connected
 - Descending tones – power off
 - Echoing chime – paired
 - low tone – min volume

TWS (True Wireless Stereo) pairing

- You can pair two speakers of this same model together.
 - Turn Bluetooth off on your device, place two matching speakers together, power them on and switch to Bluetooth mode.
 - Quick press "+" and "-" at the same time on one speaker, the speaker of the first power on will be the primary speaker, second power on is the secondary speaker.
 - They will automatically pair, when they are paired successfully and there will be a chime. The indicator for primary speaker will flash blue and the indicator for secondary speaker will stay solid blue.
 - On your device turn Bluetooth on, and pair to one of the speakers.
 - When the music is played, the primary speaker is the left channel and the secondary speaker is the right channel.
 - To maintain TWS pairing, turn Bluetooth off on your device before powering the speakers back on, the speakers will pair automatically, then re-pair with your device.
- note: To disconnect, quick press "+" and "-" at the same time on one speaker again.

Troubleshooting

- If the speaker is not working correctly, switch it on/off to restart.
- If the speaker won't turn on, recharge the battery and try again.
- If the speaker won't charge, ensure the supply works, is 5V 1A, and is not damaged.
- If the speaker makes no sound or does not show as an available device, make sure it is not paired. If so, unpair the device and re-pair the desired device.
- If the speaker cannot be operated despite being turned on, hold 'pause/play' button for 10 seconds to disconnect and reset.

Safety

- Do not expose the product to fire, high temperature, direct sunlight, etc.
- Do not modify or repair this device.
- Do not allow small particles to get into the product.
- Do not use chemical detergents to clean, use a soft dry cloth.

FCC ID: 2A023-BTSP5 Model: BTSP5 Input: 5V \approx 1A 3.7V/300mAh/1.11Wh Power Bank capacity: 300mAh

Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modification to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Target Corp. Mpls. MN, 55403 Phone: 612-304-6073

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at customersupport@gemsfindyours.com

Just what you need, priced just right.™

100% Satisfaction Guaranteed or your Money Back.

 We welcome any questions you may have at Target.com/comments or 1-800-910-6874.