3

Smart

Download Free APP: App Store GETITON
GOOGle Play

> Can't connect? Need help? Email:service.2@xmcosy.com

INTRODUCTION Thanks for choosing XMCOSY+ Wall Lights. Please read the user manual carefully and keep it for future reference. SAFETY INSTRUCTIONS Read and follow all safety instructions before installing the smart wall lights.

 These light fixtures are designed to fit standard junction boxes as defined by the National Electrical Code. Always install wiring connections in accordance with local codes, ordinances, and the National Electric Code. If you are unsure of the installation process, please consult your local electrician. Install light fixtures in the event of a power outage. Please keep children away from these lights. Keep lights away from flammables and fire sources. • Avoid placing the lights near potentially dangerous sources.

DO NOT EXCEED RATED CAPACITY. **FCC Notice:** This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions: 1. This device may not cause harmful interference. 2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply

with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. CAUTION: Suitable for indoor and outdoor use.

CONTENT **Specifications** Package Contents **Assemble** Lampshade angle adjustment -Service & Warranty --APP Download & Registration -Distribution Network & APP Connection ----- 11 **APP Functions -**Alexa Pairing Instruction ---Google Assistant Pairing Instruction----- 26 Contact -

SPECIFICATIONS XMCOSY+ **Brand** XMWLA-2 10.83" x 3.54" x 4.45" 4.72" x 4.72" 2.6KG Aluminum+ Frosted PC+ Plastic SMD LED 1400LM/EA DC 31V 16W Wattage **APP Control** YES Junction Box Standard

PACKAGE CONTENTS 1. Wall Light * 2 2. Screw A M4x30 * 8 3. Screw B M4x20 * 4 4. Wire Nut * 6 5. Arm Hex Key * 1 Mounting Bracket * 2 7. User Manual * 1 After unpacking, please check the product accessories. If there are any missing or damaged accessories, please contact us as soon as possible, and our customer service team will solve it in time. Use Screw A when installing through drilled holes. Use Screw B when installing on a junction box. service.2@xmcosy.com

ASSEMBLE Step - 1 Turn off the main power. Step - 2 Unscrew the screws to separate the mounting bracket and the (Please save these 2 original screws for later installation.)

First of all, remove the mounting bracket from the wall light. Then align and install the mounting bracket to the junction box with screw B. Step - 4 Choose a wall wire with the same nature as the light wire, and turn the wire nut to connect the two wires together. Black: NEUTRAL Green: EARTH

ASSEMBLE

Step - 3

Step - 5 350° Rotating Head Mount the wall light to the mounting bracket with the original Each wall light has two lamp heads, which can be freely adjusted Glue around the base to better prevent water from entering. Step - 6 Turn on the main power. FX/// For more scene modes and functions of the product, please connect to the XMcosy APP.

DISTRIBUTION NETWORK & APP CONNECTION

Congratulation!

Now you can use XMcosy App

5. After you edit the

5:36 7

vice(s) addoc successfully

XM Wall Light
Added successfully

Add Device

product name and save it,

click "Done" at the top right.

ASSEMBLE

within 350°. You can adjust the lighting effects you want according to the needs of the scene. . Long press - Enter the APP connection & network mode Long press the button for 5S, the light flashes quick and the product enters the distribution network mod (When the product is used for the first time, it will automatically enter the network distribution state after connecting to the power supply, without pressing any 2. Short press - ON/OFF & Change scene modes 8 modes(4 kinds of warm white and 4 kinds of color light) Short pressing the button, the mode changes in turn as follows:

APP FUNCTIONS

or white light.

RGB Color Mode

WHITE MODE& COLOR MODE

* Color Wheel - Slide the color wheel

up and down to adjust the color of the

light from a broad spectrum of colors.

to left to adjust the color temperature.

Drag the button on the wheel from right

You can choose to turn on the wall light in color light

LAMPSHADE ANGLE ADJUSTMENT

SERVICE & WARRANTY

Thank you for your support of XMCOSY+! XMCOSY+ provides a regular 1-Year Warranty. (: Not Satisfied?

If there is any problem with our product while using, Please Contact service.2@xmcosy.com We will provide you with a 100% Satisfied Solution!

We are glad that you didn't encounter any problems

with our smart wall lights. XMCOSY+ is committed to providing better products and services. Please feel free to contact us if you have any problems with the product.


Scan to email



APP DOWNLOAD & REGISTRATION Step 1: Download the XMcosy App from App Store or Google Play. \circ \bigcirc \circ 67 0 118 xmcosy 23 reviews Download Rated to: You might also like Scan the QR code to download

Step 2: Register 1. Enter your mobile phone 2. Enter the verification code.

APP DOWNLOAD & REGISTRATION




APP DOWNLOAD & REGISTRATION

3. Create a password and 4. Please enable the XMcosy App to get your Bluetooth Log in the App.


Set Password

with a module inside.

a group.



DISTRIBUTION NETWORK & APP CONNECTION



1. After power on, the light will automatically enter the connecting state (fast blinking); 2. If the light does not blink, please press and hold the button for 5~7 seconds to make the light flash and enter the APP pairing mode.

Click the pencil upon of the product page, create group, select

All Devices Living Room Master Bedro

XM Wall Light

XM Wall Light 2

●OFF *38% ▶30% ©0 €

OFF #60% 055% GOS

XM Wall Light Group = OON *100% D28% G0s

APP FUNCTIONS

the wall lights and save.


Create Group

levices in the same group can be control


M Wall Light

DISTRIBUTION NETWORK & APP CONNECTION Step 2: Register

2. Click the device you want to add and please make sure that



DISTRIBUTION NETWORK & APP CONNECTION 3. Fill in your 2.4GHz 4. The product starts to



1. The device name will be used again when paired to Amazon Alexa & Google Home for voice control. Please keep the router, mobile phone, and product as close as possible to ensure a good reception signal.

) • 🐠 Ji

2. The device name is suggested to consist of English words and Arabic numerals, please do not use special characters.

ALEXA PAIRING INSTRUCTION

b. In the popup page, input "xmcosy" in the search bar,

TO USE" in the popup page to enable the skills.

click "XMcosy" in the search result and click "ENABLE

7:05

Color White * Brightness - Slide the brightness bar to adjust the brightness from 1% * Default Color - There are 7 default colors, you can click the round color icons to choose a default color. White Mode * Color Wheel - Slide the color wheel up and down to adjust the color of the light from warm white to cool white

Drag the button on the wheel from right to left to adjust the white's temperature * Brightness - Slide the "brightness" bar to adjust the brightness of wall light from 1% to 100%, you can freely brighten or dim the lights.

ALEXA PAIRING INSTRUCTION

been successfully linked".

c. Click "Agree and link", then "Your XMcosy account has

DIY Your Color


APP FUNCTIONS

* Scene Mode: XMcosy App has a scene selection function. Press the scene button to enter the scene selection interface. You can choose your favorite scenes from 32 default scenes. You also can customize a new scene based on your favorite.




APP FUNCTIONS

when your app detects the songs. * Plan: You can set the time and customize favorite light mode when you fall asleep/wake up.



APP FUNCTIONS


* Schedule: Turn on/off automatically at preset times. * Music Sync Mode: The wall lights react in real-time countdown.



"Next Step" and "Authorize".

APP FUNCTIONS

* Left Time: The lights will turn off automatically after the * Power-on Behavior: Power Memory mode.



Schedule Power-on Behavior

* Group Control: Each wall light is controlled separately

If you want to control more wall lights together, you can create

XM Wall Light

New to Amazon? CREATE A NEW AMAZON ACCOUNT © 1999-2021 Amazon.com, Inc. or its affiliates

ALEXA PAIRING INSTRUCTION

device and in the Google Play for Android device.

Show password

Search the keywords "Amazon Alexa" in the App Store for iOS

3. Pair the Amazon Alexa APP to Amazon Echo Device

APP "Amazon Echo" are connected to the same Wi-Fi network

Important tips: please make sure the "XMcosy" app, Amazon Alexa

1. Download the Amazon Alexa APP


2. Sign in or register a new account

(follow the Amazon Echo User Manual)

4. Log in your Amazon Alexa APP

ALEXA PAIRING INSTRUCTION 5. Enable "XMcosy" skill in Alexa APP

a. Click "Skills & Games" in the MORE MENU on the Alexa APP's home page.



"Alexa, turn on light"

If you have any problem when you use this skill, you can contact us with email : andygoldenluck@gmail.com You can simply ask Alexa to turn on, turn off or dim th light. There's no need to go to the switch to adjust you Start By Saying "Alexa, turn on light" Smart Home. This skill may share device information with Amazon. Learn m This skill contains dynamic content

- Devices control permission Account details

ACCOUNT LINKING Link your XMcosy account with Amazon Alexa Your XMcosy account has been Close this window to discover smart-home devi you can control with Alexa.

ALEXA PAIRING INSTRUCTION

6. Enjoy Amazon Alexa Control Now with Amazon Alexa, you can take control the smart wall lights by asking it to change colors, turn lights on and off by using simple commands.

For example, using these Alexa commands below: "Alexa, Turn on/off {Specific light}" "Alexa, Set the {Specific light} to green" "Alexa, Set the {Specific light} to red" "Alexa, {Specific light} lights fifty" "Alexa, {Specific light} out"

{Specific light} is the device name you named on XMcosy APP.

GOOGLE ASSISTANT PAIRING INSTRUCTION

1. Download the APP Search "Google Home" in the App Store for iOS device and in the Google Play for Android device to install. 2. Sign in or register a new account 3. Pair the Google Home APP to Google Home Device (follow the on-screen steps) 4. Link XMcosy account in set up devices


a. Click the "+" icon in the upper left corner of home page, then click "set up device". Office Set up device Add person to home Create speaker group

Important tips: please make sure the XMcosy app, Google Home APP and Google Home devices are connected to the same Wi-Fi network.

GOOGLE ASSISTANT PAIRING INSTRUCTION

b. Click "Works with Google" c. Input "XMcosy" in the search bar. d. In the new window, select your XMcosy account's region,

input your XMcosy account and password, then click



GOOGLE ASSISTANT PAIRING INSTRUCTION

5. Enjoy Google Home Control Now you can take control the smart wall lights through Google Home by asking it to change

colors, turn lights on and off by using simple

For example, using these voice commands below: "Google, Turn on/off {Specific light}" "Google, Set the {Specific light} to green" "Google, Set the {Specific light} to red" "Google, {Specific light} lights fifty" "Google, {Specific light} out"

{Specific light} is the device name you named on XMcosy APP.

TROUBLESHOOTING

Cannot connect to the XMcosy App. 1. Check if the light is powered on.

2. Check if the Bluetooth on the smartphone is enabled. 3. When pairing, please ensure the smartphone is near the light. 4. If the connecting error still exists, please try to clean all apps that are running in the background then reopen the XMcosy App, or

Cannot connect to your Wi-Fi network/Disconnected. 1. Check if the light is powered on.

and the entered router password is correct. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again. 3. Please enable the XMcosy App to get your local location and Bluetooth.

2. Please make sure your Wi-Fi router is under the 2.4 GHz setting,

uninstall and reinstall the XMcosy App then repeat the setup.

Home network is 5GHz.

The wall penetration capability of 5.0GHz is weaker than 2.4GHz, which means that the outdoor signal of 5.0GHz is worse than 2.4GHz. Therefore, most smart devices support 2.4GHz networks or dual-frequency networks of 2.4GHz and 5.0GHz. 1. If you are using a dual-band router(2.4GHz and 5GHz frequency share a Wi-Fi account.), you can connect the device using the AP mode.

2. Or you can log in to the management page of your router and change the SSIDs of the 2.4 GHz and 5 GHz networks to differentiate them.

CONTACT

For questions, assistance, or support, **Please Contact:**

or scan to email

service.2@xmcosy.com

* Required Information 1. Amazon Order ID 2. Product Model NO. XMCOSY+ Customer Service Team will reply within 24 hours.

For more info. or news about XMCOSY+, pls follow XMCOSY+ social website. @Xmcosy+ @XMCOSY+

@xmcosylights @xmcosy

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference

by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation.

If there is any problem with our product while using



YOU DON'T NEED TO RETURN IT TO AMAZON WE WILL PROVIDE YOU WITH A 100% SATISFIED SOLUTION

XMCOSY+ Customer Service service.2@xmcosy.com



Lighting Expert, Brighten up Your Life