


IPALARM-C Quick Configuration Guide

I. Diagram of Connection Method


II. Power supply and network setup

1. Use the adapter to supply power to the DC port of the device (12V/1.5A);
2. One end of the network port expander is connected to the WAN port of the device, expand the LAN port: connect to the laptop's network port, expand the WAN port: connect to the router to connect to the external network;
3. Open your browser, type 192.168.251.254 in the address bar and enter;
4. On the login page, enter your user name and password (both are admin) and click the button "Login" to enter the configuration page;

5. Select "Basic Settings" in "WAN Setting", change the connection method from DHCP to 3G/4G, support telecom card, click the button "Apply". Click the button "Apply" to get the network (the antenna of the box should be connected, otherwise it will affect the signal);



6. System Settings ----> Reboot to complete configuration



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.