# ΤΟΡΟΦΝ





## ABOUT

Thank you for purchasing TOPDON BTMobile Pro Battery Tester. Designed to work on 12V batteries within the 100-2000 CCA range, TOPDON BTMobile Pro meets a variety of battery specifications including CCA, JIS, EN, DIN, SAE, IEC, etc., and also an effective detector to pinpoint the bad cell.

It adopts the most advanced conductivity detection technology to effectively help maximize the performance of your 12V & 24V vehicles, giving valuable, easy-to-understand information about the vehicle battery health, alternator's charging, and starter's cranking conditions.

The built-in ExtraSafe protections against short circuit, reverse polarity, and over voltage allow the tester to safely connect to any battery.

## **SPECIFICATION**

Operating Voltage: Clamp Line Length: Operating Temperature: Storage Temperature: Operating Humidity: Storage Humidity: Safety Protection: 8V~16V 1.2m (47.24 inch) -10°C to 45°C (14°F to 113°F) -20°C to 75°C (-4°F to 167°F) -10°C~50°C,10%-60%RH (Non-condensing) -20°C~70°C,10%-80%RH (Non-condensing) Reverse Polarity Protection

## PRODUCT DESCRIPTION

### **Indicator Display**

Green:	Successful Battery Connection
Blue:	Successful Bluetooth Connection
Red:	Error. Over temperature, or over voltage

## **Test Results Reference**

#### TEST RESULT:

Good Battery Bad Cell- Replace Recharge-Retest

#### TEST RESULT: Good Battery Bad Cell- Replace

**Recharge-Retest** 

#### **REFERENCE:**

SOH>=60%, SOC>=60% SOH<60%, SOC>=60% SOH>=60%, SOC<60%


INTERPRETATION: Good battery Bad battery. Need to replace Recharge battery, and retest

## Battery Measuring Standard & Range

CA	100-2000(A)	GB	30-200 (Ah)
CCA	100-2000(A)	IEC	100-1400(A)
BCI	100-2000(A)	EN	100-2000(A)
MCA	100-2000(A)	SAE	100-2000(A)
DIN	100-1400(A)	JIS	26A17245H52

## **GETTING STARTED**

- Step1 Download and install the App: search "BT-MOBILE PRO" in Apple Store or Google Play. NOTE: Compatible with IOS 8.0 / Android 5.0 smart devices, or newer.
- **Step2** Connect the RED Alligator Battery Clamp to the (+) positive battery terminal, and connect the BLACK Alligator Battery Clamp to the (-) negative battery terminal. Make sure the battery terminals are clean and the clamps are securely attached to the correct terminals.



## Step3

Establish the wireless communication between BTMobile Pro with your smart devices via Bluetooth 4.0. You can register with your valid email address, or skip the login procedure. NOTE: We strongly recommend the registration for latest product news and timely technical assistance.









### Step4

Select the options with guidance to run the battery test, starting test, charging test, or battery system test, according to your actual needs.

NOTE: Please turn off all electrical equipment prior to the battery testing operation.



#### Q: Can BTMobile Pro test the battery installed in the vehicle?

A: Yes, it supports in-vehicle and out-of-vehicle testing.

#### Q: Is the test result accurate?

A: Yes. Our BTMobile Pro features advanced conductance detection giving you accurate test results in seconds.

#### Q: What batteries can BTMobile Pro work on?

A: It works on 12V regular flooded, AGM Flat plate, AGM Spiral, GEL and Deep Cycle batteries, with CCA between 100 to 2000.

#### Q:Is BTMobile Pro designed with any built-in protections?

A:Yes. It offers peace of mind with extra-safe Reverse Polarity and Sparkproof protection, and easy operations even if you're new to battery testing.

#### Q:Can BTMobile Pro test 12V solar battery?

A:If your solar battery bank is made up of lead-acid cells, then yes.

#### Q: How do I confirm if my vehicle battery is bad or good?

A: The battery tester will display SOH (State of Health), SOC (State of Charge), CCA (Cold Cranking Ampere), Voltage, Internal Resistance, and Rating, with an intuitive test result of "GOOD" or "BAD" for your reference. If the internal resistance is too large, it indicates a broken battery.

#### Q: Can this battery tester estimate the remaining capacity of my battery?

A: Yes.The battery tester will display SOC (State of Charge) to express as a percentage of your battery's rated capacity, a measure of its condition to assess the potential energy.

Note that a decent SOC (State of Charge) doesn't mean the battery is in good condition. You need to refer to your battery's actual CCA Value and Internal Resistance for further analysis.

## **IMPORTANT SAFETY INSTRUCTION**

## FCC Warnings:

This device complies with Part 15 of the FCC Rules. Operation is subject to the foll owing two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.


-Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment

should be installed and operated with minimum distance 5mm between the radiator & your body

All information in this manual is based on the latest information available at the time of publication and no warranty can be made for its accuracy or completeness. TOPDON reserves the right to make changes at any time without notice.

## **PACKAGE LIST**



TOPDON BTMobile Pro \*1



health, alternation's charging, and starter's crasiking conditions. The built-in EsthaGale protections against short circuit, reverse polarity

Quick Guide \*1

CE FC RoHS

TOPDUN

Website www.topdon.com Hotline 833-629-4832 Email support@topdon.com