48.5*103.5MM 128克铜板纸 风琴折 背面印和正面一样的颜色 灰色做专色





The Find Bike is only compatible with iPhone 8 series or later phones running iOS 14.5 or later with Two-Factor Authentication turned on.

On your iPhone: Go to Settings > On your Mac: choose Apple menu > ince), then click on your fame (or Apple ID). Click you see a prompt to update account security. Then tap Update Account

A. Go to Settings.

B.Tap your name, then tap Fin

and follow the onscreen



Short press the Find Bike's power button whose, and a beep will sound to indicate that it is turned on.

power button 3 times in a row (2 short presses and the last long ss); after hearing two "beeps" the "Find Bike" is turned off. If the Find Bike has not been paired within 10 minutes, a beep will be heard and Turn on the power to continue

times in a row (4 short presses and the last long press); after hearing a beep, the "Find Bike" returns to

1. Ensure your iPhone is set up (see "Setting Up Your IPhone" above) and Open the Find My app.
 In the *Items* tab, tap Ac

5. Once your Find Bike is detected.

6. Follow the onscreen steps to name it and register it to your Apple

7. Ensure your Find Bike appears in Items. If not, forget the device. perform a factory reset on the Find Bike (see "Getting Started > Factory * Do not leave Find My app while



directions in the Maps app.

1. Open the Find My app.

3. Select your Find Bike in the

iPhone is connected to a network. and your Find Bike is in Bluetooth

range of your iPhone for a period of

time, you will receive a notification

1. Open the Find My app.

1. Open the Find My app.

5. Under Lost Mode, tap E

6. Enter your phone number/email

Find Bike can contact you, then tap

4. Fisure N

is turned on.

Tap the *Items* tab.
 Select your Find Bike in the

Tap the *Items* tab.
 Select your Find Bike in the *I*

list and scroll down.

4. Under Notifications, tap Noti
When Left Behind and turn on.

that your Find Bike has been lost (if you set up a name, the name will be

displayed, otherwise it will show Find

2. Tap the Items tab.

to be activated and used by another person. 1. Ensure that your Find Bike is connected to your

- 2. Open the Find My app.

remove.

If not connected when removing your Find Bilke from your Apple ID, it will no longer be discoverable and you will need to perform a factory reset before creating a new connection (see "Getting Started > Factory reset" above).

detected moving with another person with an Apple device over time, that person will receive a tracking alert

- (14°F) or above 35°C (95°F).

 2. Do not expose the device to an open flame, submerge
- it in water, or expose it to rain as this will damage the

- 1. Open the Find My app and tap the New tab.
 2. Select your Find Bike in the New list.
 3. Scroll down and tap New Lord New .
 4. Select a name from the list or select Custom Name.
 5. For Custom Name, input a name and select an emoji.

Removing your Find Bike from your Apple ID will allow it

If your Find Bike is separated from your iPhone and is

- 1.Do not expose the device to temperatures below -10°C
- 3. Always check for damage to the device, cables, or other accessories before using the device. If damaged, do

4. Do not attempt to disassemble damage the device in any way, as it may cause serious damage and void

5. Do not expose the device to corrosive liquids, or high humidity as they will seriously damage the device and void the warranty.

Use the included cable to charge. During charging, the status light will be orange.
When fully charged, the status light

will turn green. It is recommended to fully charge your Find Bike once every 3 months.

The Apple Find My network provides an personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS

Use of the Works with Apple badge designed to work specifically with the technology identified in the badge and has been certified by the product network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used

- How long will the battery last when fully charged?
 After activating the device, it needs to be fully charged immediately and can be used normally for 4 months. It is recommended to charge it every 3 months
- 2. How do you know the remaining power? iPhone 8 series or Later will display the remaining battery level
- 3. How long does it take to fully
- Charging indicator light
 Charging: Orange light
 Full Charging: Green light

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2 this device must accept any interference received, including interference that may cause undesired operation.
- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 1 of the FCx fuels. These infilities are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which are the difference of the relief of the tradiction of the relief of can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. Increase the separation between the equipment and

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician

