



cator	Battery Level Indicator
	Showing the current battery level
	Off

Status	Charging Status Indicator	Battery Level Indicator
Charging	On	Flashing light
Fully charged	On	On

7. Storage the Card

before next use.

Note: It is recommended not to put in more than two cards, or put in a card thicker than 2mm.



This power bank is not compatible with non-Maasafe phone cases, such as Otterbox Defender cases.

Do not use an adapter with an output of 5V/1A(5W) or less.

Compared with wired chargers, wireless chargers are more convenient

1. Kept the product at normal temperatures and in shade places. in lots of situation, but confined by current wireless technology, the charging speed is slower. 2. Do not store the product in a hot or humid environment 3. Use of a power supply or charger not recommended or sold by the

High temperatures will reduce charging speed and restrict powe which is something that happens to all wireless chargers. It is recommended that you charge your device in environments with temperatures balow 0~40°C.

Both the materials of cases and the position of your devices on the wireless charger will affect the charging speed and stability. Try to align the charging device with the coil position of the charger during charging.

product manufacturer may result in injuries to people. Operating temperature should be between 0°C to 40°C.

including the following:

8. Important Safety Instructions

When using this product, basic precautions should always be taken

5. Do not disassemble the product. Take it to a professional serviceme when repair is required. Incorrect diassembly or reassembly may result in a risk of accidents to people and damage to product.

6. If the product is not used for a long time, you should charge and discharge it every three months

7. When charging a device, the product may heat up within a certain temperature range. This is a normal operating condition.

8. In normal conditions, battery performance will slowly decline over the course of a few years.

9. Do not diapose of the product in heat or fire.

10. Do not clean the product with harmful chemicals or detergents.

11. Misuse, dropping, or excessive force may cause damage to products.

12. Well disposed the disused battery, keep cells or batteries of different electrochemical systems separate from each other.

Be aware that a discharged battery may cause fire or smoke. Tape the terminals to insulate them.

9. Warranty Clause

Users can enjoy free warranty service within 12 months of the date of purchase.

The limited warranty does not apply in the following cases:

 Any damages caused by human factors, misuse of the product, unauthorized alternation or change of parts components of the product, etc.

• Any damages caused by bad transportation or other irresistible factors such as floods, fire, lightning, earthquakes, etc.

• The company reserves the right, at its discretion, to change, modify, add or remove portions of these terms at any time

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning he equipment off and on,the user is encouraged to try to correct th interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This equipment must be installed and operated with a minimum distance of 15cm between the radiator and user body.

Support@kuulaa.cn

Kuulaa

Kuulaa is a trademark registered in the USA, EU and UK. All rights reserved

(|<)

KUULAA



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.