

Size : 85x55mm

INSTRUSTION MANUAL

TBT2701

WIRELESS CHARGER W/ PORTABLE BLUETOOTH SPEAKER



Operating Instruction

1. Pairing with mobile phone

- Long press 2-3 seconds to turn on wireless speaker. You will hear a short music sound.
- Turn on the bluetooth function of the mobile phone. Search for the accessible Bluetooth devices and select name "TBT2701" from the device list to pair, the mobile phone will show "TBT2701", if the phone is paired with wireless speaker, you will hear "dingdong" sound to connect successfully.
- After the speaker is connected you can play your music and listen.

2. Charging wireless speaker

- Insert the USB-C charging cable to the speaker, insert the other end to the power of the unit with included USB-C cable.
- Red blinking light means it is low on power. Red LED will light up when charging. The Red LED light will go off when fully-charged.

Note: When the speaker's voice is lower than normal or you hear a warning tone, please charge the speaker.

3. Wireless charging device (Optional)


- Insert the USB-C charging cable to the speaker, insert the other end to the power of the unit with included USB-C cable.
- Put the phone on the wireless charging area and make sure the phone is properly positioned for charging (most likely the center).

Note: make sure you phone is fit for the Qi standard receiving equipment.

Product Introduction


Thank you for choosing Phone Stand Wireless Speaker. This item features a wireless phone charger with portable bluetooth speaker. Please read the manual carefully.

Package Contents



Product Features

- ① Power Switch
- ② Center of Wireless Charger
- ③ Type-C Input
- ④ Microphone
- ⑤ Aux input
- ⑥ Phone Stand



Specification

Model:	TBT2701
Wireless Version:	5.0
Loudspeaker Output:	3W*2
Frequency Response:	20Hz-20KHz
Distortion:	≤1.0%
Signal-To-Noise:	≥75dB
Range:	≤10m
Wireless charging input:	12V/1.5A, 9V/2A, 5V/2A
Wireless charging output:	15W Max.
Dimension:	86x102x112mm

Warning Tips

- 1) Do not charge the speaker with other unsuitable power adaptors. It may cause damage to the speaker. The speaker must be charged properly by the given USB-C charging cable.
- 2) In order to avoid damage to your hearing and prolong the speaker's use-life, please do not listen to music for long time in high volume environment.
- 3) When a fault occurs, please immediately turn off the power switch, unplug the USB plug, prevent speaker and other components damaged.

FAQs

- 1) Why is there no sound when the speaker is turned on?
A: Make sure that you have charged the battery fully for the first time. Charging time is approx 3 hours.
- 2) Why is there no sound when playing the speaker?
A: Check the speaker is connected by you phone. If there is no connection, please reconnect and make sure you have the phone connected to the proper speaker.
- 3) How to recognize the Bluetooth speaker is fully charged?
A: When the speaker is being charged, and the red indicator is automatically turned off, it is already fully charged.
- 4) Why is the phone not charging?
A: Make sure the positioning of the phone is correct on the charger and that the power source is connected.

FCC statement:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

RF Exposure Information for BT

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.