


# TF-T61 说明书 成品尺寸：73X93mm 60g书写纸 双面印刷 胶装

中文

TRANSFORMERS




TF-T61耳挂式蓝牙耳机  
使用说明书

## 包装清单

	充电仓X1		耳机X2
	说明书&保修卡 X1		Type-C充电线 X1

## 产品示意图



## 温馨提示

- 除说明书有特殊提示的操作方式以外，请勿尝试拆卸或更换产品内的任何零件。
- 请勿将产品放入水或其他液体中，此产品非防水设计。
- 如果有液体不小心进入产品内时，请立即断开连接并移开此产品。
- 为避免触电，请在安装或拆卸产品时，确保手上没有沾水。
- 请勿将本产品放置于热源附近或直接暴露于火源附近。
- 请勿将本产品放置在有强大电磁力的环境中，否则会导致产品故障。

3

## 产品规格

蓝牙耳机：V5.4  
传输距离：≥10米  
音乐时间：约8小时  
喇叭尺寸：Φ14.2mm  
喇叭阻抗：32Ω  
充电时间：约1.5小时  
电池容量：90mAh/3.7V  
额定输入：5V=90mA

## 充电仓规格

电池容量：300mAh/3.7V  
充电时间：约1.5小时  
额定输入：5V=300mA  
(所有技术信息以实际性能为准)

## 给充电仓充电

Type-C充电线连接充电仓到5V电源适配器  
温馨提示：当耳机电池电量播报低电量提示（声音提示：叮咚，每1分钟1次）时，请及时给耳机充电



额定输入：5V=90mA(耳机)

额定输入：5V=300mA(充电仓)

## LED指示状态

开机	红蓝灯交替闪烁
关机	红灯长亮1秒熄灭
TWS配对状态	红蓝灯交替闪烁
进入设备配对状态	主耳红灯灯交替闪烁，副耳熄灭
断开连接	主耳红灯灯交替闪烁，副耳熄灭
耳机低电量提示	耳机红灯闪烁
耳机充电	耳机红灯长亮
耳机充满电	耳机红灯熄灭
清除配对	红灯长亮1秒熄灭

## 充电仓指示说明(只做参考，以实物为准)

充电仓充电状态	数码管显示当前电量，个位数字闪烁绿
充电仓充满电耳机电状态	红好长亮
充电仓充满电耳机电状态	红好长亮
给耳机充电，充电仓状态	红好长亮
耳机充满电充电仓状态	数码管以跑马灯形式显示给耳机充电
充电仓低电状态	数码管0.5秒一闪

## 产品操作说明

- ★首次连接默认为英文提示音
- ①开机：长按左/右触控键3秒，耳机灯提示音：“power on”
- ②关机：长按左/右触控键3秒，耳机灯提示音：“power off”
- 方法一：放回充电仓，合上盖子，耳机关机
- 方法二：长按左/右触控键3秒，耳机关机
- 方法三：耳机在3分钟内没有连接设备自动关机（关机提示音：“power off”）
- ③配对：步骤一：开机后，左右耳机自动互连后进入与手机配对状态（提示音：“pairing”）
- 步骤二：打开智能设备的蓝牙耳机列表，搜索“TF-T61”并连接
- 温馨提示：左右耳机出现不配对时，请恢复出厂设置，放回充电仓再打开自动配对

5

## 触摸操作

- 常规模式：音量减：单击左耳机触控键(最小提示音“咚”)；音量加：单击右耳机触控键(最大提示音“咚”)
- 音乐播放模式：播放/暂停：双击触控键；上一曲：三击左耳机触控键；下一曲：三击右耳机触控键
- 通话模式：接听/挂断来电：双击左/右耳机触控键
- 游戏/音乐模式：长按左耳机触控键2秒启动/关闭语音助手(提示音“咚”); 长按右耳机触控键2秒切换游戏/音乐模式(提示音“game mode”/“music mode”)

恢复出厂设置：方法①开机未连接状态，连击左/右耳机5次后左/右耳机关机(清除配对和连接的所有设备)；方法②开机连接状态：左/右耳机连击5次，3秒内长按10秒，清除耳机与蓝牙设备之间的配对信息后关机(提示音“power off”)

6

## 产品中有毒物质的名称及含量

部件名称	铅 Pb	汞 Hg	镉 Cd	六价铬 Cr(VI)	多溴联苯 PBB	多溴二苯醚 PBDE
印刷电路板组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本声明依据SJ/T 11364的规定编制。  
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。  
\*：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。  
注：1.表中标记“\*”的部件，皆因全球技术法规水平限制而无法实现有害物质的替代。  
2.印刷电路板组件，包括印刷电路板及其零部件、电子元件等。  
3.根据产品型号不同，您所购买的产品可能不会含有以上所有部件。

在中华人民共和国境内销售的电子电气产品必须标识此标志，标志内的数字代表在正常使用状态下的产品的环保使用期限。



7

## 保修声明

免责声明：  
本使用手册没有以任何形式的担保、立场表达或其他提示。本使用手册所提到的产品、规格及信息仅供参考，内容亦会随时更新于网页，恕不另行通知。  
保修声明：  
就本文件附带的产品做如下保证：如产品在您购买之日起十二（12）个月（“保修期”）内，在正常使用情况下因质量问题而发生损坏，能够修理的，免费修理；经厂家确认无法修理的，免费更换；修理或更换后的产品，在剩余保修期（最短不少于30天）内继续享有保修。购买日以销售发票日期为准，如无销售发票日期，则以保修期自产品出厂日期起计算。（13）个月计算。如申请保修，请先致电产品服务热线，并按我们指示的方式执行。申请保修时，您需要提供准确、完整和清晰填写的有效销售发票。

- 以上保证不适用于下列情况：
- 超过三包有效期限的；
  - 涂改保修卡，产品编码与产品本体不符；
  - 因 misuse、滥用或不当使用、使用、维护或保管而导致的故障或损坏；
  - 因不可抗力（如地震、战争、火灾等）或意外导致的故障或损坏；
  - 按键、按钮或受力过大而损坏；
  - 因使用不当造成或损坏的故障；
  - 任何因尖锐物体造成的损坏；
  - 有损坏或浸透迹象的产品；
  - 擅自篡改或修改的产品；
  - 产品在正常使用过程中发生的老化、褪色、磨损、破裂和其他损坏；
  - 如产品原有标识标签被更改或损毁，本保证将失效。

产品及随附物料的齐备和外观完好不属于保证范围，您在接收产品时当场检验并不得以任何理由提出异议。

以上保证是我们厂家所做出的全部保证，且仅在中国大陆地区境内适用。本文件的任何内容均不影响国家法律法规规定不能排除或限制的消费者权益。

服务热线：900-885-8808

8

## 保修卡

尊敬的用户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用！

用户信息	
用户姓名	电子部件
联系电话	邮政编码
通讯地址	

产品信息	
产品名称	产品型号
产品条码/编号/批号	

销售商信息	
名称	
地址	
联系电话	邮政编码
销售日期	发票号码
备注	

合格证
产品型号：_____
生产日期：_____
检验员：_____


服务热线：900-885-8808

合格证
产品型号：_____
生产日期：_____
检验员：_____

9

英文

TRANSFORMERS



TF-T61 Ear mounted BT  
headphones Instructions for use

## Packing list

	Charging compartment X1		Earphone X2
	Instruction manual & warranty card X1		Type-C charging cable X1

## Product diagram



## Warm reminders

- Do not attempt to remove or replace any parts in the product except for the operation method specifically indicated in the instruction manual.
- Do not put the product into water or any other liquids.
- If any liquid accidentally enters the product, immediately disconnect and remove the product.
- To avoid electric shock, please make sure that your hands are not stained when installing or uninstalling the product.
- Do not place this product near the heat source or directly expose it to the heat source.
- Do not place this product in a strong electromagnetic environment, otherwise it will cause the product to fail.

10

## Product specifications

Version: BT-V5.4  
Transmission distance: ≥10 meters  
Music time: about 8 hours  
Speaker size: Φ14.2mm  
Input impedance: 32Ω  
Charging time: about 1.5 hours  
Battery capacity: 90mAh/3.7V  
Rated input: 5V=90mA

## Specifications of charging compartment

Battery capacity: 300mAh/3.7V  
Charging time: about 1.5 hours  
Rated input: 5V=300mA  
(All technical information is subject to actual performance)

To charge the charging compartment  
The Type-C charging cable is connected to the charging compartment to the 5V power adapter.

Tips: When the headphone battery announces a low-power reminder (sound prompt: Tinkle, once every minute), please charge the headphones in time.



Rated input: 5V=90mA (headphones)

Rated input: 5V=300mA (charging box)

11

## LED indicates the status

Start	Red and blue lights flash alternately
Shut down	The red light turns off for 1 second
TWS pairing status	Red and blue lights flash alternately
Enter the device pairing state	The red and blue lights in the main ear flash alternately, and the secondary ears are turned off
Disconnect	The red and blue lights in the main ear flash alternately, and the secondary ears are turned off
Low power tips for headphones	Headphones flashing red
Headphone charging	Headphones have a solid red light
The headphones are fully charged	Headset red light off
Clear the pairing	The red light turns off for 1 second

## Instructions for charging silo (for reference only, subject to the physical object)

Charging Case Fully Charged	The digital tube shows the current power, and the digits flash increment
Charging Case Fully Charged	The red light is on
Charging Case Fully Charged	The red light is on
Charge the headphones, charging case status	Digital tubes are displayed in the form of running lights to charge headphones
The charging case of the headphones is fully charged	Digital display is extinguished
Low power of charging compartment	The digital tube flashes every 0.5 seconds

## Product how-to instructions

- ★The default is an English prompt tone for the first connection
- ①Start up: Long press the left/right touch button for 3 seconds, and the headphones turn on (prompt tone: "power on")
- ②Shut down: Method 1: Put it back in the charging case, close the lid, and turn off the earphone
- Method 2: Long press the left/right touch button for 3 seconds, turn off the earphone
- Method 3: The headphones automatically shut down without connecting the device within 3 minutes (shut down prompt tone: "power off")
- ③Pairing: Step 1: After turning on, the left and right headphones will automatically interconnect and enter the pairing state with the mobile phone (prompt tone: "pairing")
- Step 2: Open the BT list of smart devices, search for "TF-T61" and connect
- Tips: When the left and right headphones are not paired, please restore the factory settings, put them back in the charging case and then turn on the automatic pairing

12

## Touch operation

- General mode：Volume reduction: Click the left headphone touch button (minimum prompt tone "dongdong")；Volume plus: Click the right headphone touch button (maximum prompt tone "dong dong")
- Music playback mode：Play/Pause: Double-click the touch key；Previous song: Three-click the touch button of the left earphone；Next song: Three-click the right headphone touch button
- Call mode：Call/hang up the call: double-click the left/right headphone touch button
- Game/Music Mode：Long press the left headphone touch button for 2 seconds to start/off the voice assistant (prompt tone "dong")；Long press the right headphone touch button for 2 seconds to switch game/music mode (prompt tone "game mode" / "music mode")

## Restore factory settings

Method 1: Power-on unconnected state: After 5 times of hitting the left/right headphones, turn off the left/right ear (shut all)；Method 2: Power-on connection status: Click the left/right headphones 5 times in a row, press for 10 seconds in 3 seconds, clear the pairing information between the headphones and the BT device, and then turn off (prompt: "power off")

13

## The name and content of harmful substances in the product

Part name	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit board components	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with the provisions of SJ/T 11364.  
○ Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements specified in GB/T 26572.  
\* Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirements specified in GB/T 26572.

Note: 1. The parts marked with "\*" on the table are unable to achieve the replacement of harmful substances due to limitations in global technological development;  
2. Printed circuit board components: including printed circuit boards and their parts, electronic components, etc;  
3. Depending on the product model, the product you purchased may not contain all of the above components.

Electronic and electrical products sold in the People's Republic of China must mark this logo, the number in the logo represents the product under normal use environmental protection use period.



14

## Warranty statement

Disclaimer:  
This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:  
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired, free repair, free replacement if the manufacturer confirms that it cannot be repaired, repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). The date of purchase is subject to the date of the sales invoice, if the date of purchase cannot be determined, the warranty period shall be thirteen (13) months from the date of production. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

- The above guarantee does not apply to the following situations:
- Exceeding the validity period of three guarantees;
  - Altering the warranty card, the product code does not match the product body;
  - Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
  - Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
  2. Paper and lower builds are damaged due to excessive force;
  - Disconnection or tearing caused by excessive load;
  - Damage caused by sharp objects;
  - Products with signs of burning or flooding;
  - Damage caused by unauthorized disassembly;
  - Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product;
  - If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should inspect the product on the spot when you receive it and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only valid in China Mainland. Nothing in this document affects consumer rights that cannot be excluded or restricted by law.

Service supervision hotline: 900-885-8808

服务热线：900-885-8808

15

## Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info	
User name	Email
Contact number	Postal code
Mailing address	

Product information	
Product name	Product number
Product barcode / Serial number / Batch number	

Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	

Product number	
Production Time	
QC	

Certificate of conformity

Product number: \_\_\_\_\_

Production Time: \_\_\_\_\_

QC: \_\_\_\_\_

16

TRANSFORMERS

17

**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.