

# User Manual for Sveaverken Intelligent Heat Lamp SSSL175s

---



**Sveaverken Intelligent Technology (Shenzhen)  
Co., Ltd.**

---



Högmossevägen 11  
SE-641 39 Katrineholm  
Tel: +46-150-48 77 00,  
Fax: +46-150-48 77 77  
[www.sveaverken.com](http://www.sveaverken.com)

## Table of Contents

I. Safety Precautions .....	1
II. Product Introductions .....	2
III. Specifications .....	2
IV. Device Installation .....	3
1. Device Composition .....	3
2. System Architecture .....	4
3. Assembly Steps .....	4
V. APP Instructions .....	5
1. Homepage .....	6
2. Language Setting .....	6
3. Device Adding .....	8
4. Device Deletion .....	9
5. Device Management .....	10
6. Information Management .....	12

## I. Safety Precautions

### Note



- Please read this manual before installing, adjusting, inspecting, and maintaining the Intelligent Heat Lamp. Improper installation and operation may cause serious injury, for which the manufacturer will assume no responsibility!
- Please carefully read this manual to install and use the Sveaverken Intelligent Heat Lamp.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
- This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) this device may not cause harmful interference, and
  - (2) this device must accept any interference received, including interference that may cause undesired operation.

### WARNING



- The AC power supply should comply with the product specifications!
- Do not touch the hot lamp shade with your hands!
- The circuit, ammeter, and air switch should comply with the load requirements of the product!
- Wear PPEs during the installation, adjustment, inspection, and maintenance of the intelligent heat lamp!
- The bulb has a service life of 8000 H. At the end the life, please contact Sveaverken to purchase a

replacement to avoid affecting the lamp effect in use!

- It is quite essential to inspect and maintain the device regularly for its proper operation!
- The device which is damaged must be replaced by the manufacturer, its service agent or similar qualified team to avoid danger!

#### **DANGER**



- The bulb which is fragile must not be squeezed or hit!
- The lamp shade which is easy to deform must not be stacked or squeezed to avoid affecting the effect in use.

## **II. Product Introductions**

Temperature Control lamps are often required for poultry or livestock breeding and greenhouses. However, the traditional lamps with only two levels of brightness control may affect the growth of poultry and livestock at high or low temperature. Sveaverken Intelligent Heat Lamp is capable of adjusting the brightness based on the preset target temperature to keep the breeding sheds and greenhouses at constant temperature to avoid repeated manual adjustments, thus reducing contact between humans and animals and minimizing power consumption.

Heat lamps are particularly important for pig breeding.

Due to the high demand for temperature of piglets, the ambient temperature has an important effect on the growth and survival of piglets. The suitable temperature for piglets is 32~34 °C at birth, 30~32 °C during the first three days, 28~32 °C during the next four days, 26~28 °C within 2 weeks postpartum, 24~26 °C within 3 weeks postpartum, 24 °C after weaning, and gradually drops to the same level as the ambient environment. Traditionally, the manual adjustment of the lamp height and the repeated adjustment of brightness at the different growth stages of piglets result in huge labor costs.

The Sveaverken Intelligent Heat Lamp is capable of accurately controlling its luminous power through intelligent algorithm based on the ambient temperature in real time, saving electric energy, reducing labor costs, and improving the survival of piglets and the welfare of human and livestock.

Tests show that a 175 W traditional heat lamp consumes about 1,500 watts a year, while the Sveaverken Intelligent Heat Lamp consumes only 1,000 watts a year, saving 1/3 of the cost.

Executive standard:


Model	Executive standard
SSHL175s	GBT/23140-2009

## **III. Specifications**

### **Specifications of Sveaverken Intelligent Heat Lamp**

<b>Model</b>	SSHL175s/SSHL175
<b>Power supply voltage</b>	AC220V~AC240V
<b>Rated power</b>	175 W
<b>Hanging chain</b>	2 m stainless steel
<b>Type of light source</b>	Infrared bulb
<b>Wire length</b>	1.5 m/1.75 m/2 m/2.5 m
<b>Wire specification</b>	0.75 cm <sup>2</sup>
<b>Plug type</b>	National/American standard triangle plug/customized
<b>Dimensions</b>	300*φ330 mm
<b>Control mode</b>	IOT
<b>Bulb life</b>	>5000 h
<b>Certification</b>	CE/FCC
<b>Package</b>	10 pcs/box
<b>Remark</b>	Lamp shades and bulbs packaged separately

## IV. Device Installation




### 1. Device composition








1.1 Anti-rust iron chain, 2 m long, lamp height adjustable as required.

- 1.2 Heat-resistant lamp holder, with good flame retardance and heat dissipation effect.
- 1.3 Aluminum alloy lamp shade, with heat-resistant coating to prevent oxidation.
- 1.4 Manual switch, convenient and efficient.
- 1.5 Intelligent control box, more intelligent and energy-saving.
- 1.6 Temperature probe, with high accuracy and large range.
- 1.7 Protective net, scald prevention, easy to disassemble, maintain and clean.

## 2. System architecture



## 3. Assembly steps

		
		
	<ol style="list-style-type: none"><li>1. Align the fixing screws of the lamp holder with the fixing holes at the top of the lamp shade, and assemble the two components;</li><li>2. After fixing the lamp holder and the lamp shade, tighten the screws with a cross screwdriver</li></ol>	<ol style="list-style-type: none"><li>4. Remove the lamp protective net, and install it into the mounting groove, with one end through the net limit hole on one side of the lamp shade;</li><li>5. The installation of the protective net is completed;</li><li>6. Connect one end of the</li></ol>


	3. After aligning the lamp thread with the lamp base, turn the bulb clockwise, and tighten and fix it to the lamp base;	<p>hanging iron chain to the lamp holder, and fix the other end to the hanging position;</p> <p>7. The assembly of the heat lamp is completed;</p> <p>8. Note that the temperature probe shall be installed 4 cm below the edge of the lamp shade.</p>
--	---	--

## V. APP Instructions

The APP which is mainly designed for front-line team enables users to manage all lamps with one click via Pad. In addition to remote device management, it also supports the backup of the Pad local data to the cloud via the Internet. This APP greatly improves the management efficiency of heat lamps.

## 1. Homepage



- 1.1 Ready-to-use in local mode without login;
- 1.2 Icon-based display that delivers the real-time status of devices;
- 1.3 Top search box where you can enter keywords to quickly select devices;
- 1.4. Clicking the ON/OFF icon enables you to quickly turn on/off the bulbs;
- 1.5 Clicking the “+” on the right of the search bar enables you to scan and add nearby devices.




## 2. Language Setting

- 2.1 Click the navigation bar at the top of the homepage,
- 2.2 Go to the Setting interface
- 2.3 Set the language








### 3. Device Adding

3.1 Click “+” to display a list of nearby connectable devices

3.2 Click the device icon to complete the device information.



Intelligent Heat Lamp Control Pad

Complete Device Information


Device Name Intelligent Heat Lamp SN12345676

Installation Location For example Pigsty 01 Shed 001

Remarks Input Remarks

Add



Cancel



#### 4. Device Deletion

4.1 Press and hold the icon on the homepage to go to the Delete interface



4.2 Select the device to be deleted in the dialog box and click Delete



## 5. Device Management

5.1 Click the icon on the homepage to go to the device detail interface

5.2 Edit the device work mode, setting time, device information, and device switch



Intelligent Heat Lamp Control Pad

4G
32
8.8
13:22

Device Management

Pigsty 01 Shed 001

25.5°C
120h
80W
120kWh

Work Mode
Auto mode

Setting Time
Open

Device Information

Device Switch

Set Time

Day Repeat
Week Repeat

Monday
Add

Start time 2:02
End time 2:02

00	01	02	03
04	05	06	07
08	09	10	11
12	13	14	15
16	17	18	19
20	21	22	23

Confirm

Intelligent Heat Lamp Control Pad

4G
32
8.8
13:22

Device Management

Pigsty 01 Shed 001

25.5°C
120h
80W
120kWh

Work Mode
Auto mode

Setting Time
Open

Device Information

Device Switch

Device Name
Intelligent Heat Lamp SN12345676

Installation Location
Pigsty 01 Shed 001

Installation location not null

Remarks
Input Remarks

MAC Address
2021/05/06 13:22

Setting Time
00000000

Device SN
00000000

Cancel

Save

## 6. Information Management

